




## NetPoint Pro Family

Broadband Wireless Networking Solutions

NetPoint Pro 6x2.4 / 3x2.4 (G2 and G2M)

### CLI Reference Guide



2<sup>nd</sup> Generation

This document contains information that is proprietary to Netronics Technologies Inc.

No part of this publication may be reproduced, modified, or distributed without prior written authorization of Netronics Technologies Inc.

This document is provided as is, without warranty of any kind.

#### **Statement of Conditions**

The information contained in this document is subject to change without notice.

Netronics shall not be liable for errors contained herein or for incidental or consequential damage in connection with the furnishing, performance, or use of this document or equipment supplied with it.

#### **Information to User**

Any changes or modifications of equipment not expressly approved by the manufacturer could void the user's authority to operate the equipment and the warranty for such equipment.

Copyright © 2011 by Netronics. All rights reserved.

# READ THIS FIRST!

## Important Safety Instructions



**Caution**

Read and save these instructions. Heed all warnings. Follow all instructions.



**Caution**

Do not defeat the safety purpose of the grounding. Only use attachments/accessories specified by the manufacturer.



**Caution**

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way. For example, if the power-supply cord or plug is damaged, liquid has been spilled on the apparatus, objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, it does not operate normally, or has been dropped.



**Warning**

There is a risk of personal injury or death if the NPP-6X2.4 antennas come near electric power lines. Carefully read and follow all instructions in this manual. By nature of the installation, you may be exposed to hazardous environments and high voltage. Use caution when installing the outdoor system.



**Warning**

This apparatus must be connected to earth ground.



**Warning**

Do not open the unit. There is a risk of electric shock inside.



**Caution**

You are cautioned that any change or modification not expressly approved in this manual could void your authority to operate this equipment.



**Caution**

There are no user-serviceable parts inside. All service must be performed by qualified personnel.



**Caution**

The RJ45 connectors of your Netronics NPP-6X2.4 may source DC power On pins 4,5 and 7,8. The IEEE 802.3 standards allow for pins 4,5 and 7,8 to be used for Power Over Ethernet. Some products may be incompatible with the Netronics Power Over Ethernet capability. If such problems occur, make sure that the unit is configured with the Power Over Ethernet capability set to Off (default setting). If problems persist, use Ethernet cables that have no connections to the unused pins 4,5 and 7,8.



**Caution**

The Netronics NPP-6X2.4 and NPP-3X2.4 can be installed in wet, outdoor locations. Make sure closure caps are installed and all cable connections are securely fastened and waterproofed.



**Caution**

The Netronics NPP-6X2.4 can only be used with approved antennas.

## Table of Contents

<b>Introduction .....</b>	<b>9</b>
Scope of this Document .....	9
Organization .....	9
Conventions .....	9
<b>Using the NetPoint Pro CLI .....</b>	<b>10</b>
Configurations .....	10
Special Character Functions .....	11
Enable/Disable .....	12
Using Configuration and Remove commands .....	12
Delete .....	13
Saving Configuration Changes .....	13
Radio Interfaces .....	14
<b>NetPoint Pro CLI commands .....</b>	<b>15</b>
CONFIGURE CAC .....	15
CONFIGURE CAC ALGORITHM .....	16
CONFIGURE CAC MAC_CLASSIFIER .....	16
CONFIGURE CAC MAX_VC .....	17
CONFIGURE CAC MIN-VC-SNR .....	17
CLOCK .....	18
CLOCK SET .....	18
CONFIGURE CALIBRATION FORCE-CALIBRATION .....	19
CONFIGURE CLASSIFIER .....	19
CONFIGURE CLASSIFIER ADD .....	20
CONFIGURE CLASSIFIER REMOVE .....	20
CONFIGURE ENHANCED-OMNI .....	21
CONFIGURE INACTIVITY-TIMEOUT .....	21
CONFIGURE INTERFACE DOT11RADIO BANDWIDTH .....	22
CONFIGURE INTERFACE DOT11RADIO BEACON-PERIOD .....	22
CONFIGURE INTERFACE DOT11RADIO BEACON-RATE .....	23
CONFIGURE INTERFACE DOT11RADIO CHANNEL .....	23
CONFIGURE INTERFACE DOT11RADIO CHANNEL-LIST .....	25
CONFIGURE INTERFACE DOT11RADIO DISABLE .....	26
CONFIGURE INTERFACE DOT11RADIO DISTANCE .....	27
CONFIGURE INTERFACE DOT11RADIO DTIM-PERIOD .....	27
CONFIGURE INTERFACE DOT11RADIO ENABLE .....	28
CONFIGURE INTERFACE DOT11RADIO ERP-MODE .....	29
CONFIGURE INTERFACE DOT11RADIO FIXED-RATE .....	29
CONFIGURE INTERFACE DOT11RADIO MAX-ASSOC .....	30
CONFIGURE INTERFACE DOT11RADIO MAX-RATE .....	30
CONFIGURE INTERFACE DOT11RADIO MIN-RATE .....	31
CONFIGURE INTERFACE DOT11RADIO MODE .....	32
CONFIGURE INTERFACE DOT11RADIO PREAMBLE-MODE .....	33
CONFIGURE INTERFACE DOT11RADIO PROFILE .....	33
CONFIGURE INTERFACE DOT11RADIO RADAR-DETECTION .....	35
CONFIGURE INTERFACE DOT11RADIO RANGE-OPTIMIZATION .....	35
CONFIGURE INTERFACE DOT11RADIO RTS .....	36
CONFIGURE INTERFACE DOT11RADIO SENSITIVITY .....	36
CONFIGURE INTERFACE DOT11RADIO SERVICE .....	37
CONFIGURE INTERFACE DOT11RADIO SSID .....	38
CONFIGURE INTERFACE DOT11RADIO TXPWRATTN .....	38
CONFIGURE INTERFACE DOT11RADIO WME .....	39

CONFIGURE INTERFACE DOT11RADIO WME-ENABLE .....	40
CONFIGURE INTERFACE FASTETHERNET ADD-VLAN-TAG .....	40
CONFIGURE INTERFACE FASTETHERNET AUTO-NEGOTIATION .....	41
CONFIGURE IP DEFAULT-GATEWAY .....	41
CONFIGURE IP MTU .....	42
CONFIGURE IP SSH .....	42
CONFIGURE IP SSH AUTHENTICATION .....	43
CONFIGURE IP SSH AUTHENTICATION-RETRIES .....	43
CONFIGURE IP SSH CRYPTO KEY GENERATE .....	44
CONFIGURE IP SSH CRYPTO KEY PUBLIC-KEY .....	44
CONFIGURE IP SSH DISABLE .....	45
CONFIGURE IP TELNET .....	46
CONFIGURE IP TELNET AUTHENTICATION-RETRIES .....	46
CONFIGURE IP TELNET DISABLE .....	47
CONFIGURE IP VLAN .....	47
CONFIGURE LOGGING DEST CLI .....	48
CONFIGURE LOGGING DEST HISTORY .....	48
CONFIGURE LOGGING DEST RS232CONSOLE .....	49
CONFIGURE LOGGING MODULE .....	49
CONFIGURE LOGGING SYSLOG IP-ADDRESS .....	50
CONFIGURE MAC-FILTER LIST ADD-MAC .....	51
CONFIGURE MAC-FILTER LIST NEW .....	51
CONFIGURE MAC-FILTER LIST REMOVE-LIST .....	52
CONFIGURE MAC-FILTER LIST REMOVE-MAC .....	52
CONFIGURE MESH ADVERTISE .....	53
CONFIGURE MESH CONNECTIVITY_TEST .....	53
CONFIGURE MESH INTERFACE DOT11RADIO WDS .....	54
CONFIGURE MESH INTERFACE DOT11RADIO WDS-PEER .....	54
CONFIGURE MESH INTERFACE DOT11RADIO WDS-PRIVACY .....	55
CONFIGURE MESH FILTER-LIST .....	56
CONFIGURE MESH MODE .....	57
CONFIGURE MESH NETWORK-ID .....	57
CONFIGURE MESH PRIVACY .....	58
CONFIGURE MESH REROUTE-NOW .....	58
CONFIGURE MESH STAND-ALONE .....	59
CONFIGURE MESH STAND-ALONE-PASSPHRASE .....	59
CONFIGURE MESH TRUNK .....	60
CONFIGURE NTP .....	60
CONFIGURE PINGWD .....	61
CONFIGURE PRIVACY WEP SSID AUTH-TYPE .....	61
CONFIGURE PRIVACY WEP SSID DEFAULT-KEY .....	62
CONFIGURE PRIVACY WEP SSID INDEX .....	63
CONFIGURE PRIVACY WPA .....	63
CONFIGURE RADIUS .....	64
CONFIGURE RADIUS INTERIM-INTERVAL .....	65
CONFIGURE RADIUS RETRY-PRIMARY-INTERVAL .....	66
CONFIGURE RECOVERY-SSID .....	66
CONFIGURE SITESURVEY .....	66
CONFIGURE SNMP ROCOMMUNITY .....	67
CONFIGURE SNMP RWCOMMUNITY .....	68
CONFIGURE SSID .....	68
CONFIGURE SSID FORCED-ROUTING .....	69
CONFIGURE SSID MACFILTER .....	69
CONFIGURE SSID PRIVACY-METHOD .....	70

CONFIGURE SSID REMOVE .....	70
CONFIGURE SSID RENAME .....	71
CONFIGURE SSID SSID-PROFILE .....	71
CONFIGURE SSID TYPE .....	72
CONFIGURE SSID USER-PROFILE .....	73
CONFIGURE SSID VLAN .....	73
CONFIGURE TC .....	74
CONFIGURE TC-DEFAULT-PROFILE .....	75
CONFIGURE TC-PROFILE MODIFY .....	75
CONFIGURE TC-PROFILE NEW .....	76
CONFIGURE TC-PROFILE REMOVE .....	77
CONFIGURE TRAP-NOTIFY-FILTER .....	77
CONFIGURE TRAP-TARGET ADD .....	78
CONFIGURE TRAP-TARGET REMOVE .....	78
CONFIGURE USERNAME .....	79
CONFIGURE USERNAME MODIFY .....	80
CONFIGURE WEB .....	80
COPY RUNNING-CONFIG STARTUP-CONFIG .....	81
DELETE STARTUP-CONFIG .....	81
DISASSOCIATE-STA .....	82
EXPORT STARTUP-CONFIG .....	82
EXPORT SYSTEM-BACKUP .....	82
HOSTNAME .....	83
IMPORT IMAGE .....	83
IMPORT STARTUP-CONFIG .....	84
IPRF-CLIENT .....	84
IPRF-SERVER .....	85
MORE .....	85
PING .....	86
RELOAD .....	86
SHOW ASSOCIATED-STATIONS .....	86
SHOW CAC ACTIVE-VOIP-CLIENTS .....	87
SHOW CAC MAC_CLASSIFIER_MASKS.....	87
SHOW CAC PARAMS .....	88
SHOW CALIBRATION STATUS .....	88
SHOW CLASSIFIER .....	89
SHOW COUNTRY-CODE .....	89
SHOW DEFAULT-CONFIG .....	89
SHOW ENHANCED-OMNI .....	90
SHOW INACTIVITY-TIMEOUT .....	90
SHOW INTERFACE DOT11RADIO .....	91
SHOW INTERFACE DOT11RADIO CHANNEL-LIST .....	91
SHOW INTERFACE DOT11RADIO MESH-SCAN-RESULTS .....	92
SHOW INTERFACE DOT11RADIO PARAMS .....	92
SHOW INTERFACE DOT11RADIO PROFILE .....	93
SHOW INTERFACE DOT11RADIO RANGE-OPTIMIZATION .....	93
SHOW INTERFACE DOT11RADIO STATS .....	94
SHOW INTERFACE DOT11RADIO WME .....	94
SHOW INTERFACE FASTETHERNET .....	95
SHOW INTERFACE FASTETHERNET STATS .....	95

SHOW INTERFACE SSIDS .....	96
SHOW INTERFACE WIFI-LOAD-RATIO .....	96
SHOW INTERFACE WIFI-STATS .....	97
SHOW IP ADDRESS .....	97
SHOW IP PARAMS .....	97
SHOW IP SSH-PUBLIC-KEYS .....	98
SHOW LOGGED-IN-USERS.....	98
SHOW LOGGING DESTINATIONS .....	99
SHOW LOGGING HISTORY .....	99
SHOW LOGGING HOST .....	99
SHOW LOGGING MODULES-LEVEL .....	100
SHOW MAC-FILTER INDICES .....	100
SHOW MAC-FILTER LIST .....	101
SHOW MANUFACTURE-DETAILS .....	101
SHOW MESH INTERFACE-WDS-PARAMS .....	101
SHOW MESH FILTER-LIST .....	102
SHOW MESH PARAMS .....	102
SHOW MESH ROUTE .....	103
SHOW MESH STAND-ALONE .....	103
SHOW MESH WDS-PEER-LIST .....	103
SHOW MESSAGES .....	104
SHOW NTP .....	104
SHOW PINGWD .....	105
SHOW PRIVACY WEP .....	105
SHOW PRIVACY WEP PARAMS .....	105
SHOW PRIVACY WPA .....	106
SHOW RADIUS .....	106
SHOW RECOVERY-SSID STATUS .....	107
SHOW RUNNING-CONFIG .....	107
SHOW SITESURVEY .....	108
SHOW SNMP-COMMUNITIES .....	108
SHOW SOFTLOAD-MESSAGES .....	108
SHOW SOFTWARE-BANKS .....	109
SHOW SPECTRUM-MANAGEMENT CLEAR-COUNT-PERCENT .....	109
SHOW SPECTRUM-MANAGEMENT DOA .....	110
SHOW SSID PARAMS .....	110
SHOW STARTUP-CONFIG.....	111
SHOW SYSTEM-TEMPERATURE .....	111
SHOW TC-DEFAULT-PROFILE .....	111
SHOW TC-PROFILES .....	112
SHOW TRAP-NOTIFY-FILTERS .....	112
SHOW TRAP-TARGETS .....	113
SHOW UPTIME .....	113
SHOW USERS .....	114
SHOW VERSION .....	114
SHOW WEB STATUS .....	114



# Chapter 1

---

## Introduction

### Scope of this Document

This guide is for the networking professional using the NetPoint Pro CLI command line interface. The CLI manages NetPoint Pro access points. Before using this guide, please refer to the device user guide. Also take time to become familiar with the concepts and terminology of Wi-Fi, Ethernet and local area networking.

### Organization

This guide is organized into these sections:

[Chapter 1, “Using the Command-Line Interface”](#), describes how to access the command modes and use the command-line interface (CLI) to configure software features.

[Chapter 2, “NetPoint Pro CLI Commands for Access Points”](#), describes in alphabetical order the NetPoint Pro CLI commands used to configure and monitor the access point.

### Conventions

This publication uses the following conventions to convey instructions and information:

Command descriptions conventions:

- Commands and keywords are in **boldface** text.
- Arguments for which you supply values are in italic.
- Square brackets ([ ]) means optional elements.
- Braces ({ }) group required choices, and vertical bars ( | ) separate the alternative elements.
- Braces and vertical bars within square brackets ([{ }]) mean a required choice within an optional element.

# Chapter 2

---

## Using the NetPoint Pro CLI

### Using the NetPoint Pro CLI

The NetPoint Pro Command Line Interface (CLI) is a powerful tool to communicate with NetPoint Pro access points. CLI access is available at three levels of user privileges:

- super – The super user has the highest level of privilege.
- admin – The administrator has a medium level of privilege.
- viewer – The viewer has viewing-only privilege.

Before logging in to the NetPoint Pro CLI software, select the appropriate user level. The user level sets the subset of the available commands. To have access to all commands you must login as super user (super). Creating new user, setting a user privilege level, and setting a password is detailed in the user guide.

### Configurations

There are three types of configurations on the NetPoint Pro access point units:

- Startup – The startup configuration typically is used when starting the device. This configuration is stored in non-volatile memory.
- Running – The running configuration is the current configuration of the running device. This configuration is stored in volatile memory.
- Default – The default configuration contains predetermined default values for the specific software version. This configuration is stored in non-volatile memory.

At system start the device is configured according to the startup configuration. As a result, the configuration currently running in volatile memory is exactly the same as the startup configuration. All CLI commands executed after system start affect the running configuration. In this way, you can change the current configuration without modifying the original startup configuration. By copying the running configuration to the startup configuration, the startup configuration can be modified.

The first time a device boots or when the startup configuration has been deleted, the unit loads the default configuration. The default configuration is a predetermined group of settings released per software version. A user cannot change the default configuration. When a device is shipped from the factory its startup configuration is identical to the default configuration. When the startup configuration is missing the default settings are copied to the startup configuration and used during boot time.

Most of the commands are one-time commands. The configuration commands change the running configuration. When the running configuration is saved to the startup configuration, these commands are stored in a non-volatile environment. See Saving Configuration Changes below.

## Special Character Functions

**abbreviated-command-entry<Tab>**: Completes a partial command name.

ap> config<tab> results in ap> configure

The available commands depend on the current user level. Entering a question mark (?) at the system prompt displays a list of commands available for each command level.

? List all commands available for a particular command level.

ap>? (for example)  
configure - Configures network and system parameters of the NetPoint Pro 3x2.4 OR  
NetPoint Pro 6x2.4.  
ping - Sends ICMP ping packets.  
(etc.)

**command ?** List the keywords or arguments that you must enter next on the command line.  
(There is a space between the command and the question mark.)

ap> configure ?  
<enter> - Enter command mode  
interface - Configures network interfaces  
(etc.)

/ return to the root of the CLI command structure.

ap> configure>/  
ap>

**/<command to execute>** return to the root of the CLI command structure after executing the command.

ap> /configure <parameters> <enter>  
ap>

## Enable/Disable

Within selected commands is the ability to enable or disable a function. For example, the configure classifier command has two parameters: <codec name> and {enable | disable}.

```
configure classifier <codec name> {enable | disable}
```

When enable is selected, the specified codec is enabled. When disable is selected, the specified codec is disabled.

Another way to enable or disable a function is by using a specific command. For example,

```
configure mesh filter-list {enable | disable}
```

In this case the configure command enables or disables the use of a mesh filter list, which is based on the value “true” or “false”.

## Using Configuration and Remove commands

A configuration command defines a configuration in the running configuration.

For example, to configure an SSID:

```
ap> configure ssid 2 name Netronics vlan 0 privacy-method none type hidden
```

To unassign, to take the effect of this command out of the running configuration, execute the associated remove function. The remove functions are implemented by either the associated remove command or by the remove option.

For example to remove an existing SSID, execute the following remove command:

```
ap> configure ssid 2 remove
```

For example to remove a MAC address from the mesh filter list, execute the following command with the remove option:

```
ap> configure mesh filter-list 00:14:06:11:00:00 remove
```

Almost every configuration command has an associated remove command or remove option. In general, a configuration command causes an effect in the running configuration; “remove” takes the effect out of the running configuration.

## Delete

There are two general ways to delete something from the system. The first uses a specific delete command such as deleting the startup configuration:

**delete startup-config**

or deleting the mac-filter list:

**configure mac-filter delete <index integer>.**

Another way to delete is within a command such as deleting a specified CLI user:

**configure username <username string> delete.**

Any time something is deleted, it is only removed from the running configuration, not the startup configuration. To make the changes permanent the running configuration must be saved to the startup configuration

## Saving Configuration Changes

The concept of the three types of configuration is so important that it is repeated here.

The running configuration is non-permanent and dynamic. It changes as commands are executed in order to demonstrate the new system configuration. The running configuration does not remain over a power cycle, reboot, or system failure. This configuration can be saved to the startup configuration to make it non-volatile.

The startup configuration is non-volatile, stored in memory, and is stable over power cycle, reboot, and system failure. This configuration is loaded into the running configuration at system start.

The default settings configuration allows the startup configuration to be replaced with default settings.

To save the running configuration to the startup configuration enter the **copy running-config startup-config** command. For example:

```
ap> copy running-config startup-config
```

It might take a few seconds to save the configuration. After the configuration has been saved, the following output appears:

```
TRAP: Configuration Saved.
```

```
Configuration Action Succeeded.  
ap>
```

## Radio Interfaces

The NetPoint Pro device uses multiple radio interfaces to communicate with other NetPoint Pro devices and customer stations. Each radio interface is identified by an interface number, which is used by the CLI to configure and manage the NetPoint Pro devices. The following table lists the NetPoint Pro devices and the type of radio interfaces that they utilize:

Product Model	Product P/N	Interface 0	Interface 1	Interface 2
NetPoint Pro 6x2.4 F	NPP-ANT-6x2.4F	xRF 2.4Ghz	5.8Ghz	N/A
NetPoint Pro 6x2.4 E	NPP-ANT-6x2.4E	xRF 2.4Ghz	5.4Ghz	N/A
NetPoint Pro 6x2.4 M	NPP-ANT-6x2.4M	xRF 2.4Ghz	5.8Ghz	N/A

Only 5.4Ghz and 5.8Ghz interfaces are defined as 802.11a backhaul radio interfaces, by default.  
All 2.4Ghz and 4.9Ghz interfaces are defined as access radio interfaces, by default.

# Chapter 3

---

## NetPoint Pro CLI Commands

### NetPoint Pro CLI commands

This chapter lists and describes NetPoint Pro CLI commands in Software Release 2.6.7 that you use to configure and manage your NetPoint Pro access point. The commands are listed alphabetically.

#### CONFIGURE CAC

**Function:** Enables or disables the Call Admission Control (CAC) feature.

**Command Syntax:** `configure cac {enable | disable}`

**Command Description:**

Parameter	Value
enable   disable	enable – Enables CAC. disable – Disables CAC. The default value is disable.

**Example:** `configure cac enable`

**Permission Level:** admin

**Related Commands:**

`configure cac mac_classifier`  
`configure cac min-vc-snr`  
`show cac active-voip-clients`  
`show cac params`

## CONFIGURE CAC ALGORITHM

**Function:** Configures the current Call Admission Control (CAC) algorithm.

**Command Syntax:** `configure cac algorithm {VA1 | VA2}`

**Command Description:**

Parameter	Value
VA1   VA3	VA1 – Sets the CAC algorithm based on the number of associated VoIP devices and the SNR. VA3 – Not supported in this version of the CLI. The default value is VA1.

**Example:** `configure cac algorithm VA1`

**Permission Level:** admin

**Related Commands:**

`configure cac mac_classifier`

`configure cac min-vc-snr`

`show cac active-voip-clients`

`show cac params`

## CONFIGURE CAC MAC\_CLASSIFIER

**Function:** Configures the Call Admission Control (CAC) MAC classifier feature. This feature is used to optimize traffic with VoIP devices. The VoIP devices are identified using a MAC mask.

**Command Syntax:** `configure cac mac_classifier {enable | disable}`  
`configure cac mac_classifier {add | delete} <mac mask>`

**Command Description:**

Parameter	Value
enable   disable	enable – Enables MAC classifier. disable – Disables MAC classifier. The default value is disable.
add   delete	add – Adds a new MAC mask. delete – Deletes a MAC mask.
mac mask	MAC Mask xx:xx:xx. This parameter is used to identify the VoIP devices. Specify the first three bytes of the MAC address. This identifies the manufacturer of the devices. The value must be specified according to the following syntax (XX:XX:XX).

**Example:** `configure cac mac_classifier add 11:01:22`

**Permission Level:** admin

**Related Commands:**

```
configure cac
configure cac min-vc-snr
show cac active-voip-clients
show cac params
```

## CONFIGURE CAC MAX\_VC

**Function:** Defines the maximum number of simultaneous voice sessions on the device. The specified value defines the maximum allowed voice sessions per access channel.

**Command Syntax:** `configure cac max_vc <max_vc>`

**Command Description:**

Parameter	Value
max_vc	Maximum number of voice sessions per access channel: 0-32 The default value is 32.

**Example:** `configure cac max_vc 20`

**Permission Level:** admin

**Related Commands:**

```
configure cac
configure cac mac_classifier
show cac active-voip-clients
show cac params
```

## CONFIGURE CAC MIN-VC-SNR

**Function:** Configures the CAC minimum voice call SNR threshold.

**Command Syntax:** `configure cac min-vc-snr <threshold number>`

**Command Description:**

Parameter	Value
threshold number	Minimum Voice Call SNR threshold number: 1-100 The default value is 12.

**Example:** `configure cac min-vc-snr 20`

**Permission Level:** admin

**Related Commands:**

configure cac  
configure cac mac\_classifier  
show cac active-voip-clients  
show cac params

## CLOCK

**Function:** Displays the system clock time and date.

**Command Syntax:** `clock`

**Command Description:**

Parameter	Value
None	

**Example:** `clock`

**Permission Level:** viewer

**Related Commands:**

clock set

## CLOCK SET

**Function:** Configures the system clock settings (24 hours, local time).

**Command Syntax:** `clock set <datetime string>`

**Command Description:**

Parameter	Value
datetime string	Date and time string according to the following syntax: MMDDhhmmYYYY MM – Month DD – Date hh – Hour mm – Minute CC – Century YY – Year

**Example:** This example demonstrates how to set the clock to July 23, 2007 at

11:47:55AM.

`clock set 072311472007`

**Permission Level:** admin

**Related Commands:**

Clock

## CONFIGURE CALIBRATION FORCE-CALIBRATION

**Function:** Executes an immediate calibration of the specified 802.11b/g radio interface(s).

**Command Syntax:** **configure calibration force-calibration interface {0 | 1 | all} [{short | long}]**

**Command Description:**

Parameter	Value
0   1   all	Radio interface number: 0 – Calibrates radio interface 0. 1 – Calibrates radio interface 1. all – Calibrates all 802.11b/g radio interfaces in the unit.
short   long	Type of calibration: short – Starts a short calibration. long – Starts a long calibration. This parameter is optional. The default value is short.

**Example:** **configure calibration force-calibration interface 0 long**

**Permission Level:** super

**Related Commands:**

configure interface Dot11Radio channel

## CONFIGURE CLASSIFIER

**Function:** Configures the standard codecs that are supported by the classifier.

**Command Syntax:** **configure classifier <codec name> {enable | disable}**

**Command Description:**

Parameter	Value
codec name	Defines the standard classifier to be enabled or disabled: <b>g-711</b> – G.711 (rate 64 Kbps) codec <b>g-726</b> – G.726 (rate 24 Kbps) codec <b>g-728</b> – G.728 (rate 16 Kbps) codec <b>g-729</b> – G.729 (rate 8 Kbps) codec <b>g-723-1-rate5-3</b> – G.723.1 (rate 5.3 Kbps) codec <b>g-723-1-rate6-3</b> – G.723.1 (rate 6.3 Kbps)
enable   disable	enable – Enables the specified codec. disable – Disables the specified codec.

**Example:** This example demonstrates how to enable support for G.711 codec.  
**configure classifier g-711 enable**

**Permission Level:** admin

**Related Commands:**

configure classifier add

configure classifier remove  
show classifier

## CONFIGURE CLASSIFIER ADD

**Function:** Adds, defines, and enables a new codec.

**Command Syntax:** **configure classifier add <name string> interval <interval number> packet-size <packet-size number> [{bidirectional | unidirectional}] [jitter <jitter number>]**

**Command Description:**

Parameter	Value
name string	Name of the new codec to be configured. The value can be up to 31 characters.
interval number	Packet interval. Minimum time difference between two consecutive packets (msec): 0-5000
packet-size	Maximum packet size (bytes): 20-2347
bidirectional   unidirectional	Pack direction: bidirectional – Packet direction is bidirectional. unidirectional – Packet direction is in the downstream direction towards the client. The default value is unidirectional.
jitter number	Jitter size. Defines the time variation of intervals between two consecutive packets (msec): 0-50 Maximum time interval between two consecutive packets is defined by the time values for <i>interval number + jitter number</i> . The default value is 15 (15 msec).

**Example:** configure classifier add new-codec interval 20 packet-size 80

**Permission Level:** admin

**Related Commands:**

configure classifier  
configure classifier remove  
show classifier

## CONFIGURE CLASSIFIER REMOVE

**Function:** Deletes and disables the codec specified, including standard codecs. When an added codec is specified, it is removed from the running configuration.

**Command Syntax:** **configure classifier remove <name string>**

**Command Description:**

Parameter	Value
name string	Name of the codec all

**Example:** configure remove g-711

**Permission Level:** admin

**Related Commands:**

configure classifier  
configure classifier add  
show classifier

## CONFIGURE ENHANCED-OMNI

**Function:** Enables and disables the enhanced omni mode.

**Command Syntax:** **configure enhanced-omni {enable | disable}**

**Command Description:**

Parameter	Value
enable   disable	enable – Enables the enhanced omni mode. disable – Disables the enhanced omni mode. The default mode is disable.

**Example:** configure enhanced-omni enable

**Permission Level:** admin

**Related Commands:**

show enhanced-omni

## CONFIGURE INACTIVITY-TIMEOUT

**Function:** Configures the CLI timeout. Defines the time that the CLI automatically logs off the user when the user session is not active.

**Command Syntax:** **configure inactivity-timeout <timeout number>**

**Command Description:**

Parameter	Value
timeout number	CLI timeout period (minute): 1-90 The default value is 10 (10 minutes).

**Example:** configure inactivity-timeout 30

**Permission Level:** admin

**Related Commands:**

show inactivity-timeout

## CONFIGURE INTERFACE DOT11RADIO BANDWIDTH

**Function:** Configures the bandwidth on the specified radio interface.

**Command Syntax:** `configure interface Dot11Radio <interface number> bandwidth {5 | 10 | 20 | 40}`

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
5   10   20   40	Bandwidth: 5 – 5 Mhz 10 – 10 Mhz 20 – 20 Mhz 40 – 40 Mhz The default value is 20 (20 Mhz).

**Example:** `configure interface Dot11Radio 0 bandwidth 40`

**Permission Level:** super

**Related Commands:**

`show interface Dot11Radio params`

## CONFIGURE INTERFACE DOT11RADIO BEACON-PERIOD

**Function:** Configures the time period between transmitting beacons by the specified radio interface.

**Command Syntax:** `configure interface Dot11Radio <interface number> beacon-period <period number>`

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
period number	Time period between beacons (msec): 100-1000 Default value for 802.11a interface is 200 (200 msec). Default value for 802.11b/g interface is 250 (250 msec).

**Example:** `configure interface Dot11Radio 0 beacon-period 200`

**Permission Level:** admin

**Related Commands:**

```
show interface Dot11Radio
show interface Dot11Radio params
```

## CONFIGURE INTERFACE DOT11RADIO BEACON-RATE

**Function:** Configures the transmitted beacon-rate on the specified radio interface.

**Command Syntax:** **configure interface Dot11Radio <interface number> beacon-rate <rate number>}**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
<rate number>	Beacon-Rate: 1 – 1 Mbps 2 – 2 Mbps 5.5 – 5.5 Mbps 6 – 6 Mbps 11 – 11 Mbps 12 – 12 Mbps The default value is 1 (1 Mbps).

**Example:** configure interface Dot11Radio 0 beacon-rate 2

**Permission Level:** super

**Related Commands:**

```
show interface Dot11Radio
show interface Dot11Radio params
```

## CONFIGURE INTERFACE DOT11RADIO CHANNEL

**Function:** Configures the Wi-Fi channel used on the specified radio interface. The actual frequencies available are dependent on the radio interface (802.11a or 802.11b/g) and the region to which the unit was manufactured. To display all available channels for the specified radio interface, use the *show interface Dot11Radio channel-list* command.

**Command Syntax:** **configure interface Dot11Radio <interface number> channel {<channel number> | default | auto}**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio

---

interfaces are used for 2.4GHz communications.

---

<channel number> | default | auto

Channel and Frequencies IEEE 802.11b/g:

1– 2412 Mhz	9– 2447 Mhz
2– 2417 Mhz	10– 2452 Mhz
3– 2422 Mhz	11– 2457 Mhz
4– 2427 Mhz	12– 2462 Mhz
5– 2432 Mhz	13– 2467 Mhz
6– 2437 Mhz	

---

Default value for Dot11Radio 0 is channel 4 (2427 MHz).

---

<channel number> | default | auto (continue)

Channel and Frequencies for IEEE 802.11a:

34 – 5170 Mhz	108 – 5540 MHz
36 – 5180 Mhz	112 – 5560 Mhz
38 – 5190 Mhz	116 – 5580 Mhz
40 – 5200 Mhz	120 – 5600 Mhz
42 – 5210 Mhz	124 – 5620 Mhz
44 – 5220 Mhz	128 – 5640 Mhz
46 – 5230 Mhz	132 – 5660 Mhz
48 – 5240 Mhz	136 – 5680 Mhz
52 – 5260 Mhz	140 – 5700 Mhz
56 – 5280 Mhz	149 – 5745 Mhz
60 – 5300 Mhz	153 – 5765 Mhz
64 – 5320 Mhz	157 – 5785 Mhz
100 – 5500 Mhz	161 – 5805 Mhz
104 – 5520 Mhz	165 – 5825 Mhz

---

Default channel for 802.11a radio is 161 (5805 MHz).

Channel and Frequencies for 4.9GHz Public Safety:

20 – 4950 Mhz
30 – 4955 Mhz
40 – 4960 Mhz
50 – 4965 Mhz
60 – 4970 Mhz
70 – 4975 Mhz
80 – 4980 Mhz

---

Default channel for 4.9 GHz Public Safety is 20 (4950 MHz).

default – Sets the Wi-Fi channel to the default channel for the specified radio interface.

auto – The Wi-Fi channel is automatically selected by the system. The automatic selection of the channel is performed only after restarting the unit. After the restart, the unit performs a site survey and then selects the best channel available.

**Example:** configure interface Dot11Radio 0 channel 6

**Permission Level:** admin

**Related Commands:**

configure interface Dot11Radio channel-list  
 configure sitesurvey  
 show interface Dot11Radio  
 show interface Dot11Radio params  
 show interface Dot11Radio channel-list  
 show sitesurvey

## CONFIGURE INTERFACE DOT11RADIO CHANNEL-LIST

**Function:** Defines the allowable Wi-Fi channels that can be selected for the specified radio interface. The actual frequencies available are dependent on the radio interface (802.11a or 802.11b/g) and the region to which the unit was manufactured. To display all available and allowable channels for the specified radio interface, use the *show interface Dot11Radio channel-list* command.

**Command Syntax:** **configure interface Dot11Radio <interface number> channel-list {un-allow | allow} <channel number> | all}**

**Command Description:**

Parameter	Value																
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.																
un-allow   allow	un-allow – Prohibits the specified channel or all channels from use by the specified radio interface. allow – Permits the specified channel or all channels from use by the specified radio interface.																
<channel number>   all	Channel and Frequencies IEEE 802.11b/g:  <table> <tbody> <tr><td>1– 2412 Mhz</td><td>8– 2442 Mhz</td></tr> <tr><td>2– 2417 Mhz</td><td>9– 2447 Mhz</td></tr> <tr><td>3– 2422 Mhz</td><td>10– 2452 Mhz</td></tr> <tr><td>4– 2427 Mhz</td><td>11– 2457 Mhz</td></tr> <tr><td>5– 2432 Mhz</td><td>12– 2462 Mhz</td></tr> <tr><td>6– 2437 Mhz</td><td>13– 2467 Mhz</td></tr> </tbody> </table>	1– 2412 Mhz	8– 2442 Mhz	2– 2417 Mhz	9– 2447 Mhz	3– 2422 Mhz	10– 2452 Mhz	4– 2427 Mhz	11– 2457 Mhz	5– 2432 Mhz	12– 2462 Mhz	6– 2437 Mhz	13– 2467 Mhz				
1– 2412 Mhz	8– 2442 Mhz																
2– 2417 Mhz	9– 2447 Mhz																
3– 2422 Mhz	10– 2452 Mhz																
4– 2427 Mhz	11– 2457 Mhz																
5– 2432 Mhz	12– 2462 Mhz																
6– 2437 Mhz	13– 2467 Mhz																
<channel number>   all	Channel and Frequencies for IEEE 802.11a:  <table> <tbody> <tr><td>34 – 5170 Mhz</td><td>108 – 5540 Mhz</td></tr> <tr><td>36 – 5180 Mhz</td><td>112 – 5560 Mhz</td></tr> <tr><td>38 – 5190 Mhz</td><td>116 – 5580 Mhz</td></tr> <tr><td>40 – 5200 Mhz</td><td>120 – 5600 Mhz</td></tr> <tr><td>42 – 5210 Mhz</td><td>124 – 5620 Mhz</td></tr> <tr><td>44 – 5220 Mhz</td><td>128 – 5640 Mhz</td></tr> <tr><td>46 – 5230 Mhz</td><td>132 – 5660 Mhz</td></tr> <tr><td>48 – 5240 Mhz</td><td>136 – 5680 Mhz</td></tr> </tbody> </table>	34 – 5170 Mhz	108 – 5540 Mhz	36 – 5180 Mhz	112 – 5560 Mhz	38 – 5190 Mhz	116 – 5580 Mhz	40 – 5200 Mhz	120 – 5600 Mhz	42 – 5210 Mhz	124 – 5620 Mhz	44 – 5220 Mhz	128 – 5640 Mhz	46 – 5230 Mhz	132 – 5660 Mhz	48 – 5240 Mhz	136 – 5680 Mhz
34 – 5170 Mhz	108 – 5540 Mhz																
36 – 5180 Mhz	112 – 5560 Mhz																
38 – 5190 Mhz	116 – 5580 Mhz																
40 – 5200 Mhz	120 – 5600 Mhz																
42 – 5210 Mhz	124 – 5620 Mhz																
44 – 5220 Mhz	128 – 5640 Mhz																
46 – 5230 Mhz	132 – 5660 Mhz																
48 – 5240 Mhz	136 – 5680 Mhz																

---

52 – 5260 Mhz	140 – 5700 Mhz
56 – 5280 Mhz	149 – 5745 Mhz
60 – 5300 Mhz	153 – 5765 Mhz
64 – 5320 Mhz	157 – 5785 Mhz
100 – 5500 Mhz	161 – 5805 Mhz
104 – 5520 Mhz	165 – 5825 Mhz
all – Permits or prohibits the all channels from use by the specified radio interface.	

---

**Example:** configure interface Dot11Radio 0 channel 6

**Permission Level:** admin

**Related Commands:**

configure interface Dot11Radio channel  
 configure sitesurvey  
 show interface Dot11Radio  
 show interface Dot11Radio params  
 show interface Dot11Radio channel-list  
 show sitesurvey

## CONFIGURE INTERFACE DOT11RADIO DISABLE

**Function:** Disables the specified radio interface.

**Command Syntax:** **configure interface Dot11Radio <interface number> disable**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.

---

**Example:** configure interface Dot11Radio 0 disable

**Permission Level:** super

**Related Commands:**

configure interface Dot11Radio enable  
 show interface Dot11Radio  
 show interface Dot11Radio params  
 show interface Dot11Radio stats

## CONFIGURE INTERFACE DOT11RADIO DISTANCE

**Function:** Defines the distance between the gateway and the node units for the 802.11a backhaul radio interface. For 802.11b/g access radio interface, this command defines the distance between the node unit and the client. These values are used to optimize the Wi-Fi protocol time intervals for long distance usage on the specified radio interface. The distance specified for the 802.11a backhaul radio interface is based on the distance between the gateway and the furthest node in the network.

The distance for the 802.11a backhaul radio interface should be specified as follows:

- For a maximum distance of 1200 meters or less, specify 1200.
- For a maximum distances greater than 1200 meters, specify the actual distance.
- Specify the same value for all units in the network.

The distance specified for the 802.11b/g access radio interfaces is based on the distance between the node and the furthest client in the network.

**Command Syntax:** `configure interface Dot11Radio <interface number> distance <distance>`

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
distance	Distance in meters: 0 – 8192 Default value for 802.11a interface is 1200 (1200 meters). Default value for 802.11b/g interface is 300 (300 meters).

**Example:** `configure interface Dot11Radio 2 distance 1800`

**Permission Level:** super

**Related Commands:**

`show interface Dot11Radio`  
`show interface Dot11Radio params`  
`show interface Dot11Radio stats`

## CONFIGURE INTERFACE DOT11RADIO DTIM-PERIOD

**Function:** Configures how frequently the DTIM (Delivery Traffic Indication Message) informs the client in power saving mode if data is waiting to be sent. Each beacon contains a DTIM. The DTIM informs the client if data is waiting and when the next time data is available. The DTIM period defines the number of beacons that are broadcasted between sending data packets.

If the DTIM period is set to four, every fourth beacon contains a DTIM informing the client whether or not data is waiting.

**Command Syntax:** `configure interface Dot11Radio <interface number> dtim-period <period number>`

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
period number	DTIM Period: 1-8 The default value is 1.

**Example:** `configure interface Dot11Radio 0 dtim-period 4`

**Permission Level:** admin

**Related Commands:**

## CONFIGURE INTERFACE DOT11RADIO ENABLE

**Function:** Restarts the specified radio interface.

**Command Syntax:** `configure interface Dot11Radio <interface number> enable`

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.

**Example:** `configure interface Dot11Radio 0 enable`

**Permission Level:** admin

**Related Commands:**

`configure interface Dot11Radio disable`  
`show interface Dot11Radio`  
`show interface Dot11Radio params`  
`show interface Dot11Radio stats`

## CONFIGURE INTERFACE DOT11RADIO ERP-MODE

**Function:** Enables and disables the ERP mode. The ERP mode is used to reduce collisions when there are b and g clients. This feature is only available on 802.11b/g radio interfaces.

**Command Syntax:** **configure interface Dot11Radio <interface number> erp-mode {enable | disable}**

**Command Description:**

Parameter	Value
interface number	Access radio interface number. Specify an 802.11b/g radio interface. Depending on the unit, the value can be set to 0 or 1 for units with three interfaces, or only to 0 for units with two interfaces.
enable   disable	enable – Enables ERP mode. disable – Disables ERP mode. The default mode is disable.

**Example:** configure interface Dot11Radio 0 erp-mode enable

**Permission Level:** admin

**Related Commands:**

show interface Dot11Radio params

## CONFIGURE INTERFACE DOT11RADIO FIXED-RATE

**Function:** Configures the transmission rate on the specified radio interface.

**Command Syntax:** **configure interface Dot11Radio <interface number> fixed-rate {auto | rate <rate number>}**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5 GHz communications and all other radio interfaces are used for 2.4 GHz communications.
auto   rate	rate – Sets the transmission rate to a fixed rate. auto – The transmission rate will be automatically selected by the system. The default value is auto.
rate number	Transmission Rate: 1 – 1 Mbps 2 – 2 Mbps 5 – 5.5 Mbps 6 – 6 Mbps 9 – 9 Mbps 11 – 11 Mbps 12 – 12 Mbps 18 – 18 Mbps 24 – 24 Mbps 36 – 36 Mbps 48 – 48 Mbps

---

54 – 54 Mbps

---

**Example:** configure interface Dot11Radio 0 fixed-rate 12

**Permission Level:** super

**Related Commands:**

show interface Dot11Radio params

## CONFIGURE INTERFACE DOT11RADIO MAX-ASSOC

**Function:** Defines the maximum number of associated clients supported on the specified radio interface.

**Command Syntax:** **configure interface Dot11Radio <interface number> max-assoc <maximum associated clients>**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
maximum associated clients	Maximum number of associated clients: 1-250 The default value is 250.

**Example:** configure interface Dot11Radio 0 max-assoc 100

**Permission Level:** super

**Related Commands:**

show interface Dot11Radio params

## CONFIGURE INTERFACE DOT11RADIO MAX-RATE

**Function:** Configures the maximum transmission rate on the specified radio interface.

**Command Syntax:** **configure interface Dot11Radio <interface number> max-rate {<rate number> | auto}**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces.
<rate number>   auto	Sets the maximum transmission rate on the specified radio interface. Maximum Transmission Rate: 1 – 1 Mbps 2 – 2 Mbps 5 – 5.5 Mbps 6 – 6 Mbps 9 – 9 Mbps 11 – 11 Mbps 12 – 12 Mbps 18 – 18 Mbps 24 – 24 Mbps 36 – 36 Mbps 48 – 48 Mbps 54 – 54 Mbps The default value is 36 (36 Mbps). Auto – The maximum transmission rate will be automatically selected by the system.

**Example:** configure interface Dot11Radio 0 max-rate 48

**Permission Level:** super

**Related Commands:**

configure interface Dot11Radio min-rate  
show interface Dot11Radio params

## CONFIGURE INTERFACE DOT11RADIO MIN-RATE

**Function:** Configures the minimum transmission rate on the specified radio interface.

**Command Syntax:** **configure interface Dot11Radio <interface number> min-rate {<rate number> | none | auto}**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
<rate number>   auto	Sets the minimum transmission rate on the specified radio interface. Minimum Transmission Rate: 5.5 – 5.5 Mbps 11 – 11 Mbps 12 – 12 Mbps 18 – 18 Mbps 24 – 24 Mbps 36 – 36 Mbps auto – The minimum transmission rate will be automatically selected by the system. The default value is auto.

**Example:** configure interface Dot11Radio 0 min-rate 36

**Permission Level:** super

**Related Commands:**

configure interface Dot11Radio max-rate  
show interface Dot11Radio params

## CONFIGURE INTERFACE DOT11RADIO MODE

**Function:** Configures the Wi-Fi mode of the specified radio interface.

**Command Syntax:** **configure interface Dot11Radio <interface number> mode {a | b | g | mixed | pureg}**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
a   b   g   mixed   pureg	Actual available modes are dependent on the radio interface type.
	a – Enables the specified radio interface to communicate with 802.11a stations.
	b – Limits the specified access radio interface to communicate only with 802.11b clients.
	g – Limits the specified access radio interface to communicate only with 802.11g clients.
	mixed – Enables the specified access radio interface to communicate with 802.11b and 802.11b\g clients.
	pureg – Limits the specified access radio interface to communicate only at 802.11g rates (6 Mbps, 12 Mbps, 18 Mbps, 24 Mbps, 36 Mbps, 48 Mbps and 54 Mbps – OFDM rates)

**Example:** configure interface Dot11Radio 0 mode g

**Permission Level:** admin

**Related Commands:**

show interface Dot11Radio  
show interface Dot11Radio params

## CONFIGURE INTERFACE DOT11RADIO PREAMBLE-MODE

**Function:** Configures the preamble mode of the specified access radio interface. The preamble mode identifies the transmitted packet as a Wi-Fi packet. This feature is only available on 802.11b/g radio interfaces.

There are two types of preamble modes:

- Long – The long preamble is 192 microseconds. It is only used with 802.11b packets.
- Short – The short preamble is 96 microseconds. It is used with 802.11b and 802.11g packets.

**Command Syntax:** `configure interface Dot11Radio <interface number> preamble-mode {long | auto}`

**Command Description:**

Parameter	Value
interface number	Access radio interface number. Specify an 802.11b/g radio interface. Depending on the unit, the value can be set to 0 or 1 for units with three interfaces, or only to 0 for units with two interfaces.
long   auto	<p>long – Sets the preamble mode to long.</p> <p>auto – Sets the preamble mode to auto. The preamble mode will automatically selected between short or long.</p> <p>The default value is long</p>

**Example:** `configure interface Dot11Radio 0 preamble-mode auto`

**Permission Level:** admin

**Related Commands:**

`show interface Dot11Radio params`

## CONFIGURE INTERFACE DOT11RADIO PROFILE

**Function:** Defines the assigned traffic shape profile for the specified radio interface. The profile is only used when the specified radio interface supports mesh service. Changing the assign profile affects the traffic performance.

There are four predefined traffic shape profiles available. The following tables describe these profiles:

**Profile 1**

Category ID	AIFS	CWMax	CWMin	TXOP
besteffort	3	4	2	1000
background	7	4	2	1000
video	1	3	1	1000
voice	1	2	1	1000

**Profile 2**

Category ID	AIFS	CWMax	CWMin	TXOP
besteffort	3	6	4	1000
background	7	10	4	1000
video	1	4	3	1000
voice	1	3	2	1000

**Profile 3**

Category ID	AIFS	CWMax	CWMin	TXOP
besteffort	3	10	6	1000
background	7	10	6	1000
video	1	6	4	1000
voice	1	3	2	1000

**Profile 4**

Category ID	AIFS	CWMax	CWMin	TXOP
besteffort	3	10	8	1000
background	7	10	8	1000
video	1	6	4	1000
voice	1	3	2	1000

**Command Syntax:**    **configure interface Dot11Radio <interface number> profile <profile number>**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
profile number	Traffic shape profile number: 1-4 The default value is 2.

**Example:**           **configure interface Dot11Radio 0 profile 3**

**Permission Level:**   **super**

**Related Commands:**

**configure interface Dot11Radio service**  
**show interface Dot11Radio profile**

## CONFIGURE INTERFACE DOT11RADIO RADAR-DETECTION

**Function:** Enables or disables radar detection on the specified 802.11a radio interface. When enabled, the unit scans for radar. If radar is detected, the unit selects a channel that does not interfere with the radar.

**Command Syntax:** **configure interface Dot11Radio <interface number> radar-detection {enable | disable}**

**Command Description:**

Parameter	Value
interface number	Backhaul radio interface number. Specify an 802.11a radio interface. Depending on the unit, the value can be set to 2 for units with three interfaces, or to 1 for units with two interfaces. The last interface is used for 5GHz communications (802.11a) and all other radio interfaces are used for 2.4GHz communications (802.11b/g).
enable   disable	enable – Enables radar detection. disable – Disables radar detection. The default value is disable.

**Example:** **configure interface Dot11Radio 1 radar-detection enable**

**Permission Level:** super

**Related Commands:**

show interface Dot11Radio params

## CONFIGURE INTERFACE DOT11RADIO RANGE-OPTIMIZATION

**Function:** Defines the type of optimization that is implemented for the calibration of the RX sensitivity on the specified 802.11b/g radio interface. The calibration can be optimized for maximum range, maximum throughput or normal operation.

When the calibration is optimized for range, the throughput is reduced. When the calibration is optimized for throughput, the range is reduced. This feature is only supported on the NetPoint Pro 6x2.4 and NetPoint Pro 3x2.4 units.

**Command Syntax:** **configure interface Dot11Radio <interface number> range-optimization <optimization type>**

**Command Description:**

Parameter	Value
interface number	Access radio interface number. Specify an 802.11b/g radio interface. Depending on the unit, the value can be set to 0 or 1 for units with three interfaces, or only to 0 for units with two interfaces.
optimization type	Type of optimization: range – Calibrates the RX sensitivity for maximum range. throughput – Calibrates the RX sensitivity for maximum throughput. none – Calibrates the RX sensitivity for normal operation. The default value is normal.

**Example:** configure interface Dot11Radio 1 range-optimization range

**Permission Level:** super

**Related Commands:**

configure interface Dot11Radio sensitivity  
show interface Dot11Radio params  
show interface wifi-load-radio  
show interface wifi-stats  
show interface Dot11Radio range-optimization

## CONFIGURE INTERFACE DOT11RADIO RTS

**Function:** Configures the threshold packet size for implementing RTS. Packets larger than the RTS threshold will be transmitted using RTS. The lower the threshold the more frequently the system uses RTS.

**Command Syntax:** **configure interface Dot11Radio <interface number> rts <threshold number>**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
threshold number	RTS threshold value (byte): 1-2346 The default value is 2346 (2346 bytes).

**Example:** configure interface Dot11Radio 0 rts 1024

**Permission Level:** admin

**Related Commands:**

show interface Dot11Radio params

## CONFIGURE INTERFACE DOT11RADIO SENSITIVITY

**Function:** Configures noise floor level in dBm for the specified radio interface. All signals below the sensitivity setting are assumed to be noise and the unit does not recognize this signal.

**Command Syntax:** **configure interface Dot11Radio <interface number> sensitivity <level number>**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Specify a radio interface. Depending on the unit, the value can be set to 0, 1 or 2.
level number	Sensitivity Level (dBm): (-101) - (-77) – For xRF radio interface (-96) - (-72) – For non-xRF 802.11b/g radio interface (-89) - (-60) – For 802.11a radio interface auto – Enables automatic noise floor setting. The default value is auto

**Example:** configure interface Dot11Radio 0 sensitivity -101

**Permission Level:** admin

**Related Commands:**

show interface Dot11Radio params  
show interface wifi-load-radio  
show spectrum-management clear-count-percent

**CONFIGURE INTERFACE DOT11RADIO SERVICE**

**Function:** Configures the type of service the specified radio interface supports.

**Command Syntax:** **configure interface Dot11Radio <interface number> service {access | backhaul}**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
access   backhaul	access – Supports only access services - no mesh service. backhaul – Supports only mesh service - no access service.

**Example:** configure interface Dot11Radio 0 service access

**Permission Level:** admin

**Related Commands:**

show interface Dot11Radio  
show interface Dot11Radio params

## CONFIGURE INTERFACE DOT11RADIO SSID

**Function:** Configures the SSID for the specified access radio interface. It attaches and detaches an existing SSID from the interface.

**Command Syntax:** `configure interface Dot11Radio <interface number> ssid <index number> {add | remove}`

**Command Description:**

Parameter	Value
interface number	Access radio interface number. Specify an 802.11b/g radio interface. Depending on the unit, the value can be set to 0 or 1 for units with three interfaces, or only to 0 for units with two interfaces.
index number	SSID index number: 1-8
add   remove	add – Attaches an existing SSID to the interface. remove – Detaches an existing SSID to the interface.

**Example:** `configure interface Dot11Radio 0 ssid 4 add`

**Permission Level:** admin

**Related Commands:**

`show interface ssids`  
`show ssid params`

## CONFIGURE INTERFACE DOT11RADIO TXPWRATTN

**Function:** Configures the transmission power attenuation. It decreases the transmitted power by the specified dB value.

**Command Syntax:** `configure interface Dot11Radio <interface number> txPwrAttn <pwr>`

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
pwr	Transmission Power Attenuation (dB): 0-32 The default value is 0 (0 dB).

**Example:** `configure interface Dot11Radio 1 txPwrAttn 2`

**Permission Level:** admin

**Related Commands:**

`show interface Dot11Radio params`

## CONFIGURE INTERFACE DOT11RADIO WME

**Function:** Configures the WME quality of service (QoS) parameters for each category on the specified radio interface.

**Command Syntax:** **configure interface Dot11Radio <interface number> wme {voice | video | besteffort | background} [cw\_min <cw min number>] [cw\_max <cw max number>] [aifs <slots number>] [txop-limit <time limit>]**

### Command Description:

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
voice   video   besteffort   background	voice – Specifies the voice WME category. video – Specifies the video WME category. besteffort – Specifies the best-effort WME category. background – Specifies the background WME category.
cw min number	Minimum contention window: 0-15 Default values: For voice – 2 For video – 3 For besteffort – 4 For background – 4 This parameter is optional.
cw max number	Maximum contention window: 0-15 Default values: For voice – 3 For video – 4 For besteffort – 10 For background – 10 This parameter is optional.
slots number	AIFS time period in number of slots: 0-15 Default values: For voice – 2 For video – 2 For besteffort – 3 For background – 7 This parameter is optional.
time limit	Transmission Opportunity Duration (microseconds): 0-8192 Default values: For voice – 1504 (1.504 msec) For video – 3008 (3.008 msec) For besteffort – 0 For background – 0 This parameter is optional.

**Example:** configure interface Dot11Radio 0 wme voice aifs 1

**Permission Level:** super

**Related Commands:**

configure interface Dot11Radio wme-enable  
 show interface Dot11Radio params  
 show interface Dot11Radio wme

**CONFIGURE INTERFACE DOT11RADIO WME-ENABLE**

**Function:** Enables or disables WME on the specified radio interface.

**Command Syntax:** **configure interface Dot11Radio <interface number> wme-enable {true | false}**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
true   false	true – Enables WME. false – Disables WME.

**Example:** configure interface Dot11Radio 0 wme-enable true

**Permission Level:** super

**Related Commands:**

configure interface Dot11Radio wme  
 show interface Dot11Radio params

**CONFIGURE INTERFACE FASTETHERNET ADD-VLAN-TAG**

**Function:** Adds VLAN tagging for traffic on the FastEthernet interface. This command can also change the VLAN tag ID. To remove VLAN tagging on the FastEthernet interface set the VLAN tag ID to 0. This command is only relevant for mesh nodes.

**Command Syntax:** **configure interface FastEthernet <interface number> add-vlan-tag <vlan number>**

**Command Description:**

Parameter	Value
interface number	FastEthernet interface number. In this version the interface is always set to 0.
vlan number	VLAN tag index number: 0-4095 To remove VLAN tagging set to 0. The default value is 0.

**Example:** configure interface FastEthernet 0 add-vlan-tag 7

**Permission Level:** super

**Related Commands:**

configure interface FastEthernet auto-negotiation  
show interface FastEthernet

**CONFIGURE INTERFACE FASTETHERNET AUTO-NEGOTIATION**

**Function:** Configures the FastEthernet interface. This command allows you to configure the interface manually or by auto-negotiation.

**Command Syntax:** **configure interface FastEthernet <interface number> auto-negotiation enable**  
**configure interface FastEthernet <interface number> auto-negotiation disable speed {10 | 100} {half-duplex | full-duplex}**

**Command Description:**

Parameter	Value
interface number	FastEthernet interface number. In this version the interface is always set to 0.
enable   disable	enable – Auto-negotiation is enabled. No additional parameters need to be defined for the FastEthernet interface. disable – Auto-negotiation is disabled. The speed and the duplex mode can be configured.
10   100	Defines the speed of the FastEthernet interface: 10 – 10 Mbps 100 – 100 Mbps
half-duplex   full-duplex	Defines the Duplex Mode: half-duplex – The FastEthernet interface is set to half-duplex. full-duplex – The FastEthernet interface is set to full-duplex.

**Example:** configure interface FastEthernet 0 auto-negotiation disable speed 100 full-duplex

**Permission Level:** admin

**Related Commands:**

configure interface FastEthernet add-vlan-tag  
show interface FastEthernet

**CONFIGURE IP DEFAULT-GATEWAY**

**Function:** Configures the default gateway. This is only relevant if the IP address has been configured manually. It is not relevant if you use a DHCP server. This command should only be used when communicating with the unit via the console port.

**Command Syntax:** **configure ip default-gateway {<ip ip-address> | disable}**

**Command Description:**

Parameter	Value
ip ip-address	IP address of the default gateway.

---

disable	Deletes the default gateway configuration.
---------	--

---

**Example:** configure ip default-gateway 192.168.250.1

**Permission Level:** admin

**Related Commands:**

configure ip vlan  
show ip address

## CONFIGURE IP MTU

**Function:** Defines the Maximum Transmission Unit (MTU) of the IP packet. This command is used to define the maximum management commands IP packet size. The MTU command should be used when external equipment connected to the network cannot support the default MTU size of 1500 bytes.

**Command Syntax:** **configure ip mtu <mtu>**

**Command Description:**

Parameter	Value
mtu	Size of the MTU (bytes): 128-1500 The default value is 1500 bytes.

---

**Example:** configure ip mtu 128

**Permission Level:** admin

**Related Commands:**

show ip params

## CONFIGURE IP SSH

**Function:** Enables the SSH (Secure Shell) service. When enabled, SSH authentication is required to connect to the device for management access. This is enabled by default.

**Command Syntax:** **configure ip ssh**

**Command Description:**

Parameter	Value
None	

---

**Example:** configure ip ssh

**Permission Level:** super

**Related Commands:**

configure ip ssh authentication  
configure ip ssh authentication-retries  
configure ip ssh disable  
configure ip vlan  
show ip params  
show ip ssh-public-keys

## CONFIGURE IP SSH AUTHENTICATION

**Function:** Configures the SSH (Secure Shell) authentication method for the SSH management access connection.

**Command Syntax:** **configure ip ssh authentication {password | publicKey}**

**Command Description:**

Parameter	Value
password   publicKey	SSH authentication method: password – Password authentication publicKey – Public key authentication

**Example:** configure ip ssh authentication password

**Permission Level:** admin

**Related Commands:**

configure ip ssh  
configure ip ssh authentication-retries  
configure ip ssh crypto key generate  
configure ip ssh crypto key public-key  
configure ip vlan  
show ip params  
show ip ssh-public-keys

## CONFIGURE IP SSH AUTHENTICATION-RETRIES

**Function:** Configures the number of authentication retries for the SSH (Secure Shell) management access connection.

**Command Syntax:** **configure ip ssh authentication-retries <retries number>**

**Command Description:**

Parameter	Value
retries number	Number of authentication retries: 1-5 The default value is 3.

**Example:** configure ip ssh authentication-retries 5

**Permission Level:** admin

**Related Commands:**

configure ip ssh  
configure ip ssh authentication  
configure ip ssh crypto key generate  
configure ip ssh crypto key public-key  
configure ip ssh disable  
configure ip vlan  
show ip params  
show ip ssh-public-keys

## CONFIGURE IP SSH CRYPTO KEY GENERATE

**Function:** Configures and generates the cryptography key for the SSH (Secure Shell) management access connection.

**Command Syntax:** **configure ip ssh crypto key generate {rsa | dsa} [<length number>]**

**Command Description:**

Parameter	Value
rsa   dsa	rsa – Generates the RSA key. dsa – Generates the DSA key.
length number	Configures the key length in bits: 512-2048 This parameter is optional. The default value is 1024.

**Example:** configure ip ssh crypto key generate rsa

**Permission Level:** admin

**Related Commands:**

configure ip ssh  
configure ip ssh authentication  
configure ip ssh authentication-retries  
configure ip ssh crypto key public-key  
configure ip ssh disable  
configure ip vlan  
show ip params  
show ip ssh-public-keys

## CONFIGURE IP SSH CRYPTO KEY PUBLIC-KEY

**Function:** Configures the public authentication key for the SSH (Secure Shell) management access connection.

**Command Syntax:** `configure ip ssh crypto key public-key {add {ssh-dss | ssh-rsa} <key string> [<key string>] owner <owner string> | remove <owner string>`

**Command Description:**

Parameter	Value
add   remove   remove-all	add – Adds a new authenticated public key. remove – Deletes the user and public key from the list. remove-all – Deletes all the users and public keys from the list.
ssh-dss   ssh-rsa	Defines the key type: ssh-dss – Defines the new public key as a DSA key type. ssh-rsa – Defines the new public key as an RSA key type.
key string	A string value that defines the key string of the public key. Each string value can be up to 256 characters and is case sensitive. Up to two string values can be specified and a space must be entered between the two string values.
owner string	A string value that defines the owner name of the public key. The value can be up to 32 characters and is case sensitive.

**Example:** `configure ip ssh crypto key public-key add ssh-dss PublicKey owner Netronics`

**Permission Level:** admin

**Related Commands:**

`configure ip ssh`  
`configure ip ssh authentication`  
`configure ip ssh authentication-retries`  
`configure ip ssh disable`  
`configure ip ssh crypto key generate`  
`configure ip vlan`  
`show ip params`  
`show ip ssh-public-keys`

**CONFIGURE IP SSH DISABLE**

**Function:** Disables the SSH (Secure Shell) service. SSH is enabled by default.

**Command Syntax:** `configure ip ssh disable`

**Command Description:**

Parameter	Value
None	

**Example:** `configure ip ssh disable`

**Permission Level:** super

**Related Commands:**

`configure ip ssh`  
`configure ip ssh authentication`

configure ip ssh authentication-retries  
configure ip vlan  
show ip params  
show ip ssh-public-keys

## CONFIGURE IP TELNET

**Function:** Enables Telnet management access connection. Telnet is enabled by default.

**Command Syntax:** `configure ip telnet`

**Command Description:**

Parameter	Value
None	

**Example:** `configure ip telnet`

**Permission Level:** admin

**Related Commands:**

configure ip telnet authentication-retries  
configure ip telnet disable  
show ip params

## CONFIGURE IP TELNET AUTHENTICATION-RETRIES

**Function:** Defines the number of authentication retries.

**Command Syntax:** `configure ip telnet authentication-retries <retries number>`

**Command Description:**

Parameter	Value
retries number	Number of authentication retries: 1-5

**Example:** `configure ip telnet authentication-retries 3`

**Permission Level:** admin

**Related Commands:**

configure ip telnet  
configure ip telnet disable  
show ip params

## CONFIGURE IP TELNET DISABLE

**Function:** Disables Telnet management access connection. Telnet is enabled by default.

**Command Syntax:** `configure ip telnet disable`

**Command Description:**

Parameter	Value
None	

**Example:** `configure ip telnet disable`

**Permission Level:** admin

**Related Commands:**

`configure ip telnet`  
`configure ip telnet authentication-retries`  
`show ip params`

## CONFIGURE IP VLAN

**Function:** Configures the management IP address and VLAN ID.

**Command Syntax:** `configure ip vlan {<vlan number> | none} {<address ip-address> [<mask ipaddress>] | dhcp} [default-gateway <gateway ip-address>]`

**Command Description:**

Parameter	Value
<code>&lt;vlan number&gt;   none</code>	VLAN index number: 1-4095 Specify none to set the VLAN ID to 0 with no VLAN tagging.
<code>address ip-address</code>	IP address of the management VLAN.
<code>mask ip-address</code>	Subnet Mask of the management VLAN. This parameter is optional when specifying the IP address. The default value is 255.0.0.0.
<code>dhcp</code>	Defines that the DHCP server automatically assigns the IP address.
<code>gateway ip-address</code>	IP address of the default gateway.

**Example:** `configure ip vlan 6 192.168.250.1`

**Permission Level:** admin

**Related Commands:**

`configure ip default-gateway`  
`show ip address`

## CONFIGURE LOGGING DEST CLI

**Function:** Configures the maximum level of messages in the log that are sent to the CLI. The level defines the level of details in the log that are sent.

**Command Syntax:** `configure logging dest cli {level <level> | enable | disable}`

**Command Description:**

Parameter	Value
level   enable   disable	level – Configures the logging level that are sent to the CLI. enable – Logging has been enabled and logs are sent to the CLI. disable – Logging has been disabled and no logs are sent to the CLI. The default value is disable.
level	The level that represents the level of details sent to the CLI: emergency – Only emergency messages are sent. alert – Emergency and alert messages are sent. critical – Emergency, alert and critical messages are sent. error – Emergency, alert, critical and error messages are sent. The default value is emergency.

**Example:** `configure logging dest cli level critical`

**Permission Level:** super

**Related Commands:**

`show logging destinations`

## CONFIGURE LOGGING DEST HISTORY

**Function:** Configures the maximum level of messages in the log that are sent to the history stored in the RAM. The level defines the level of details in the log that are sent. The configuration of the history is also the configuration of the system log.

**Command Syntax:** `configure logging dest history {level <level> | enable | disable}`

**Command Description:**

Parameter	Value
level   enable   disable	level – Configures the logging level that are sent to the history. enable – Logging has been enabled and logs are sent to the history. disable – Logging has been disabled and no logs are sent to the history. The default value is disable.
level	The level that represents the level of details sent to the CLI: emergency – Only emergency messages are sent. alert – Emergency and alert messages are sent. critical – Emergency, alert and critical messages are sent. error – Emergency, alert, critical and error messages are sent. The default value is emergency.

**Example:** `configure logging dest history level critical`

**Permission Level:** super

**Related Commands:**

show logging destinations  
show logging history  
show messages

## CONFIGURE LOGGING DEST RS232CONSOLE

**Function:** Configures the maximum level of messages in the log that are sent to the console. The level defines the level of details in the log that are sent.

**Command Syntax:** `configure logging dest rs232console {level <level> | enable | disable}`

**Command Description:**

Parameter	Value
level   enable   disable	level – Configures the logging level that are sent to the console. enable – Logging has been enabled and logs are sent to the CLI. disable – Logging has been disabled and no logs are sent to the console. The default value is disable.
level number	The level number that represents the level of details sent to the console: emergency – Only emergency messages are sent. alert – Emergency and alert messages are sent. critical – Emergency, alert and critical messages are sent. error – Emergency, alert, critical and error messages are sent. The default value is emergency.

**Example:** `configure logging dest rs232console level critical`

**Permission Level:** super

**Related Commands:**

show logging destinations

## CONFIGURE LOGGING MODULE

**Function:** Configures the log level of the modules. The level defines the level of details saved in the log.

**Command Syntax:** `configure logging module {level <level> | enable | disable}}`

**Command Description:**

Parameter	Value
level   enable   disable	level – Configures the level of details that are recorded for the specified module. enable – Logging has been enabled and logs are sent to the CLI. disable – Logging has been disabled and no logs are recorded for the specified module. The default value is level.

---

level number	The level number that represents the level of details saved in the log: emergency – Only emergency messages are sent. alert – Emergency and alert messages are sent. critical – Emergency, alert and critical messages are sent. error – Emergency, alert, critical and error messages are sent. The default value is error.
--------------	---

---

**Example:** configure logging module level critical

**Permission Level:** super

**Related Commands:**

show logging modules-level

## CONFIGURE LOGGING SYSLOG IP-ADDRESS

**Function:** Configures a host to receive the module log. Defines the host IP address, port and log level. The level defines the level of details saved in the log.

**Command Syntax:** **configure logging syslog ip-address <host ipaddress> [port <port number>] {level <level> | enable | disable}**

**Command Description:**

Parameter	Value
host ipaddress	IP address of the host. The default value is 127.0.0.1.
port number	Number of the port in the host: 1-65535 This parameter is optional. The default value is 514.
level   enable   disable	level – Configures the logging level that are sent to the CLI. enable – Logging has been enabled and logs are sent to the CLI. disable – Logging has been disabled and no logs are sent to the CLI. The default value is disable.
level	The level that represents the level of details sent to the CLI: emergency – Only emergency messages are sent. alert – Emergency and alert messages are sent. critical – Emergency, alert and critical messages are sent. error – Emergency, alert, critical and error messages are sent. The default value is emergency.

---

**Example:** configure logging syslog ip-address 1.1.1.3 port 514 enable

**Permission Level:** super

**Related Commands:**

show logging host  
show logging destinations

## CONFIGURE MAC-FILTER LIST ADD-MAC

**Function:** Adds a MAC address to an existing MAC Address list. This list is used to permit or deny access to a specified SSID.

**Command Syntax:** `configure mac-filter list <index number> add-mac <macaddr>`

**Command Description:**

Parameter	Value
index number	Index number of an existing MAC filter list: 1-16
macaddr	MAC address of the client to be added to the list.

**Example:** `mac-filter list 3 add-mac 00:14:06:11:00:00`

**Permission Level:** super

**Related Commands:**

`configure mac-filter list new`  
`configure mac-filter list remove-mac`  
`show mac-filter indices`  
`show mac-filter list`

## CONFIGURE MAC-FILTER LIST NEW

**Function:** Creates a new white or black MAC filter list. This list is used to permit or deny client access to the unit.

When creating a new list, an list index number must be specified for this list. Use this index number to use, configure or delete the list. To display all filter list indices use the *show mac-filter indices* command.

**Command Syntax:** `configure mac-filter list <index number> new <name string> type {white | black}`

**Command Description:**

Parameter	Value
index number	Index number of the new MAC filter list: 1-16
name string	A string value that defines the name of the new filter list. The value is case sensitive and can be up to 32 characters.
white   black	Type of filter list: white – Filter list can be used to permit client access. black – Filter list can be used to deny client access.

**Example:** `configure mac-filter list 2 new WhiteList2 type white`

**Permission Level:** super

**Related Commands:** `mac-filter`

configure mac-filter list remove-list  
configure mac-filter list add-mac  
configure mac-filter list remove-mac  
show mac-filter indices

## CONFIGURE MAC-FILTER LIST REMOVE-LIST

**Function:** Deletes the specified MAC filter list. Specify the filter list by its index number. To display all filter list indices use the *show mac-filter indices* command.

**Command Syntax:** **configure mac-filter list <index number> remove-list**

**Command Description:**

Parameter	Value
index number	Index number of an existing MAC filter list: 1-16

**Example:** configure mac-filter list 2 remove-list 2

**Permission Level:** super

**Related Commands:**

configure mac-filter list new  
show mac-filter indices

## CONFIGURE MAC-FILTER LIST REMOVE-MAC

**Function:** Deletes a MAC address from an existing MAC Address list. This list is used to permit or deny access to a specified SSID.

**Command Syntax:** **configure mac-filter list <index number> remove-mac <macaddr>**

**Command Description:**

Parameter	Value
index number	Index number of an existing MAC address list: 1-16
macaddr	MAC address of the client to be deleted from the list.

**Example:** configure mac-filter list 3 remove-mac 00:14:06:11:00:00

**Permission Level:** super

**Related Commands:**

configure mac-filter list new  
configure mac-filter list add-mac  
show mac-filter indices  
show mac-filter list

## CONFIGURE MESH ADVERTISE

**Function:** Configures advertising this unit as a candidate for the next hop in the mesh network. It defines whether the unit that can be used to establish a connection to get access to the Mesh-Gateway.

**Command Syntax:** `configure mesh advertise {enable | disable}`

**Command Description:**

Parameter	Value
enable   disable	enable – Enables advertising, which defines this unit as a candidate for the next hop in the mesh network. disable – Disables advertising. The default value is enable.

**Example:** `configure mesh advertise disable`

**Permission Level:** admin

**Related Commands:**

`configure mesh interface`  
`configure mesh mode`  
`show mesh params`

## CONFIGURE MESH CONNECTIVITY\_TEST

**Function:** Configures the mesh-gateway connectivity test. This test is typically used to check connectivity to the Internet. This test is only applied when the unit is defined as the Mesh-Gateway. The test performs a ping command every 10 seconds. A failure mode occurs after 10 ping commands fail consecutively. If the connectivity test fails, the mesh mode will automatically switch to the node mode. When the connection is restored, the mesh mode will automatically return to the gateway mode. To display the current status of the mesh-gateway connectivity test, use the `show mesh params` command.

**Command Syntax:**

```

configure mesh connectivity_test target_host <target> | none
configure mesh connectivity_test {enable | disable}
configure mesh connectivity_test {{enable | disable} [{target_host
<target string(0-64)> | none } [target_host2 <target string(0-64)> |
none]} [timeout<timeout integer>] [retry<retry integer>]
[interval<interval integer>]}]}

```

**Command Description:**

Parameter	Value
<code>target_host</code>	Configures the host target for the connectivity test.
<code>&lt;target&gt;   none</code>	Target Definition. Specify the target IP address or host name. The name can be up to 64 characters. Specify none to only check the internal Ethernet port. The default value is none.
<code>enable   disable</code>	enable – Enables the mesh-gateway connectivity test. This is only active when the mesh mode is set to gateway.

---

disable – Disables the mesh-gateway connectivity test.  
The default value is disable.

---

**Example:** configure mesh connectivity\_test enable

**Permission Level:** admin

**Related Commands:**

configure mesh mode  
show mesh params

## CONFIGURE MESH INTERFACE DOT11RADIO WDS

**Function:** Enables or disables WDS mode on the specified radio interface. WDS services are only available when the radio interface is in access mode.

**Command Syntax:** **configure mesh interface Dot11Radio <interface number> wds {enable | disable}**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
enable   disable	enable – Enables WDS. disable – Disables WDS. The default value is disable.

---

**Example:** configure mesh interface Dot11Radio 0 wds enable

**Permission Level:** super

**Related Commands:**

configure mesh interface Dot11Radio wds-peer  
configure mesh interface Dot11Radio wds-privacy  
show mesh interface wds-params  
show mesh route  
show mesh wds-peer-list

## CONFIGURE MESH INTERFACE DOT11RADIO WDS-PEER

**Function:** Defines the associated peers of a static mesh network for the specified radio interface. Each unit must define the peers to which it is directly communicating.

To display the current mesh peers associated with the unit, use the *show mesh route* command.

**Note:** Caution should be used when configuring the mesh peers manually. Improper configuration can result with network loops.

**Command Syntax:** Configure mesh interface Dot11Radio <interface number> wds-peer <address macaddress> [remove]

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
macaddress	MAC address of the peer to be added or removed from the list.
remove	remove – Removes a peer from the list of associated peers by deleting its MAC address from the list.

**Example:** configure mesh interface Dot11Radio 0 wds-peer 00:14:06:11:00:00

**Permission Level:** super

**Related Commands:**

configure mesh interface Dot11Radio wds  
 configure mesh interface Dot11Radio wds-privacy  
 show mesh interface wds-params  
 show mesh route  
 show mesh wds-peer-list

## CONFIGURE MESH INTERFACE DOT11RADIO WDS-PRIVACY

**Function:** Configures the WDS privacy on the specified radio interface.

**Command Syntax:** **configure mesh interface Dot11Radio <interface number> wds-privacy**  
 none

**configure mesh interface Dot11Radio <interface number> wds-privacy**  
 wep key {40 | 104} <key hex>  
**configure mesh interface Dot11Radio <interface number> wds-privacy**  
 AES passphrase <passphrase string>

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
none   wep key  AES passphrase	Defines the WDS privacy method: none – WDS is configured without any encryption. wep key – Configures WEP encryption on the selected WDS interface. The WEP key must be defined. AES passphrase – Configures WPA AES encryption on the selected WDS interface. The WPA passphrase must be defined.

---

40   104	Defines the length of the WEP key: 40 – 40 bit key 104 – 104 bit key
key hex	Defines the key used for WEP security. For a 40 bit key specify a 5 octet string in hexadecimal format. (Example: 01:23:45:67:89) For a 104 bit key specify a 13 octet string in hexadecimal format. (Example: 01:23:45:67:89:01:23:45:67:89:01:23:45)
passphrase string	Defines the passphrase used during the key handshake process for AES encryption. The value is case sensitive and can be from 8 to 63 characters.

---

**Example:**      `configure mesh interface Dot11Radio 0 wds-privacy wep key 40 01:23:45:67:89`

**Permission Level:**    super

**Related Commands:**

`configure mesh interface Dot11Radio wds`  
`configure mesh interface Dot11Radio wds-peer`  
`show mesh interface wds-params`  
`show mesh route`  
`show mesh wds-peer-list`

## CONFIGURE MESH FILTER-LIST

**Function:**      Configures and enables mesh filtering. It is used to limit the structure of the mesh. Mesh filtering defines a list of MAC addresses that can be denied or permitted connectivity to the mesh interface.

**Command Syntax:**    `configure mesh filter-list mac <macaddress> {add | remove}`  
`configure mesh filter-list type {permit | deny}`  
`configure mesh filter-list {enable | disable}`

**Command Description:**

Parameter	Value
mac	MAC address of the peer to be added or removed from the mesh filter list. The value is displayed in the following syntax (XX:XX:XX:XX:XX:XX).
add   remove	add – Adds the specified MAC address to the mesh filter list. remove – Removes the specified MAC address from the mesh filter list.
permit   deny	permit – Defines the mesh filter list as a white MAC filter list. These MAC addresses will be permitted connectivity to the mesh interface. deny – Defines the mesh filter list as a black MAC filter list. These MAC addresses will be denied connectivity to the mesh interface.
enable   disable	enable – Enables mesh filtering. disable – Disables mesh filtering. The default value is disable.

---

**Example:**      `configure mesh filter-list mac 00:14:06:11:00:00 add`  
`configure mesh filter-list type permit`

configure mesh filter-list enable

**Permission Level:** super

**Related Commands:**

configure mesh interface  
configure mesh mode  
show mesh filter-list  
show mesh params

## CONFIGURE MESH MODE

**Function:** Configures the unit as a Mesh-Gateway or Mesh-Node.

**Command Syntax:** **configure mesh mode {gateway | node}**

**Command Description:**

Parameter	Value
gateway   node	gateway – Defines the unit as the Mesh-Gateway. node – Defines the unit as a Mesh-Node. The default value is node.

**Example:** configure mesh mode gateway

**Permission Level:** admin

**Related Commands:**

configure mesh interface  
show mesh params

## CONFIGURE MESH NETWORK-ID

**Function:** Defines the mesh network id associated with the unit. All units in a single mesh network have the same specified network id.

**Command Syntax:** **configure mesh network-id <network-id>**

**Command Description:**

Parameter	Value
network-id	A string value that defines the name of the mesh network. The value is case sensitive and can be from 8 to 16 characters.

**Example:** configure mesh network-id private

**Permission Level:** admin

**Related Commands:**

configure mesh interface

configure mesh mode  
show mesh params

## CONFIGURE MESH PRIVACY

**Function:** Configures the mesh privacy. This is used to give security for the data transmitted in the mesh network.

**Command Syntax:**

- configure mesh privacy none**
- configure mesh privacy wep key {40 | 104} <key hex>**
- configure mesh privacy AES passphrase <passphrase string>**

**Command Description:**

Parameter	Value
none   wep   AES	Defines the mesh privacy method: none – Mesh works without security. wep key – Connects to other NetPoint Pro 6x2.4 and NetPoint Pro 3x2.4 units using WEP security. The WEP key must be defined. AES passphrase – Connects to other NetPoint Pro 6x2.4 and NetPoint Pro 3x2.4 units using WPA security. The WPA passphrase must be defined.
40   104	Defines the length of the WEP key: 40 – 40 bit key 104 – 104 bit key
key hex	Defines the key used for WEP security. For a 40 bit key specify a 5 octet string in hexadecimal format. (Example: 01:23:45:67:89) For a 104 bit key specify a 13 octet string in hexadecimal format. (Example: 01:23:45:67:89:01:23:45:67:89:01:23:45)
passphrase string	Defines the passphrase used during the key handshake process for AES encryption. The value is case sensitive and can be from 8 to 63 characters.

**Example:** configure mesh privacy wep key 40 01:23:45:67:89

**Permission Level:** admin

**Related Commands:**

configure mesh interface  
configure mesh mode  
show mesh params

## CONFIGURE MESH REROUTE-NOW

**Function:** Scans and connects to the best available next hop to establish a connection to get access to the Mesh-Gateway. This command temporarily disables its connections to all peers prior to connecting to the best available next hop.

**Command Syntax:** **configure mesh reroute-now**

**Command Description:**

Parameter	Value
None	

**Example:** configure mesh reroute-now**Permission Level:** admin**Related Commands:**

configure mesh interface  
 configure mesh mode  
 show mesh params

**CONFIGURE MESH STAND-ALONE**

**Function:** Configures the mesh stand-alone mode. When the stand-alone mode is active, the device acknowledges that it does not have communications with the gateway and disables access to the clients.

**Command Syntax:** **configure mesh stand-alone {enable | disable | force-stay}**

**Command Description:**

Parameter	Value
enable   disable   force-stay	enable – Enables the mesh stand-alone mode. If the device loses communications with the gateway, the device changes its stand-alone status to an active state. disable – Disables the mesh stand-alone mode. If the stand-alone status is active, it changes its stand-alone status to an inactive state. force-stay – If the device loses communications with the gateway, the device changes its stand-alone status to an active state. When communications returns to the gateway, the stand-alone status stays in the active state. The default mode is enable.

**Example:** configure mesh stand-alone disable**Permission Level:** super**Related Commands:**

configure mesh stand-alone-passphrase  
 configure mesh interface  
 configure mesh mode  
 configure mesh stand-alone-passphrase  
 show mesh params  
 show mesh stand-alone

**CONFIGURE MESH STAND-ALONE-PASSPHRASE**

**Function:** Configures the mesh stand-alone SSID pre-shared key.

**Command Syntax:** **configure mesh stand-alone-passphrase <passphrase string>**

**Command Description:**

Parameter	Value
passphrase string	Defines the passphrase used during the key handshake process. The value is case sensitive and can be from 8 to 63 characters.

**Example:** configure mesh stand-alone-passphrase password

**Permission Level:** admin

**Related Commands:**

configure mesh stand-alone  
 configure mesh interface  
 configure mesh mode  
 configure mesh stand-alone  
 show mesh params  
 show mesh stand-alone

**CONFIGURE MESH TRUNK**

**Function:** Enables and disables the mesh trunk mode.

**Command Syntax:** **configure mesh trunk {enable | disable}**

**Command Description:**

Parameter	Value
enable   disable	enable – Enables the mesh trunk mode. disable – Disables the mesh trunk mode. The default mode is enable.

**Example:** configure mesh trunk enable

**Permission Level:** admin

**Related Commands:**

show mesh params

**CONFIGURE NTP**

**Function:** Configures the Network Time Protocol (NTP) client on the unit.

**Command Syntax:** **configure ntp host {<ipaddress> | <hostname>} interval <time>**  
**configure ntp host {enable | disable}**

**Command Description:**

Parameter	Value
ipaddress	IP address of the NTP server.
hostname	Host name of the NTP server.
time	Defines the time interval used to synchronize the unit's system clock with the NTP server (seconds). 1 – 2147483647

---

enable   disable	enable – Enables the NTP daemon. disable – Disables the NTP daemon. The default value is disable.
------------------	---

---

**Example:** configure ntp host 192.168.0.1 interval 10

**Permission Level:** super

**Related Commands:**

show ntp

## CONFIGURE PINGWD

**Function:** Configures and enables the ping watchdog feature. When enabled, the unit sends a ping to a specified IP address. If there is no response to the ping the unit reboots.

This feature is used to confirm communications during a reconfiguration of the unit. If communications is lost due to a configuration error, the unit will reboot and restore a valid configuration.

The configuration of this feature is not saved to the startup configuration. It is recommended that you configure this feature prior to any configuration updates to the unit.

**Command Syntax:** **configure pingwd ip <ip address> timeout <time>**  
**configure pingwd {enable | disable}**  
**ip <ip address> timeout <time>**

**Command Description:**

Parameter	Value
ip address	IP address of the remote host.
time	Defines the time interval that the unit sends the ping packets (seconds). 1 – 3600 The default value is 10 seconds.
enable   disable	enable – Enables the ping watchdog feature. disable – Disables the ping watchdog feature. The default value is disable.

---

**Example:** configure pingwd ip 192.168.0.2 timeout 10

**Permission Level:** super

**Related Commands:**

show pingwd

## CONFIGURE PRIVACY WEP SSID AUTH-TYPE

**Function:** Configures the WEP authentication algorithm to a specific SSID.

**Command Syntax:** **configure privacy wep ssid <index number> auth-type {open | shared}**

**Command Description:**

Parameter	Value
index number	SSID index number. 1-8
open   shared	Defines the authentication type: open – Open system authentication. shared – Shared key authentication.

**Example:** configure privacy wep ssid 3 auth-type open

**Permission Level:** admin

**Related Commands:**

configure privacy wep ssid index  
 configure ssid  
 show ssid params  
 show privacy wep  
 show privacy wep params

**CONFIGURE PRIVACY WEP SSID DEFAULT-KEY**

**Function:** Configures the default WEP key index to a specific SSID.

**Command Syntax:** **configure privacy wep ssid <index number> default-key <key index>**

**Command Description:**

Parameter	Value
index number	SSID index number. 1-8
key index	Defines the WEP key index number. 1-4 In this version the index number is always set to 1.

**Example:** configure privacy wep ssid 3 default-key 1

**Permission Level:** admin

**Related Commands:**

configure privacy wep ssid index  
 configure ssid  
 show ssid params  
 show privacy wep  
 show privacy wep params

## CONFIGURE PRIVACY WEP SSID INDEX

**Function:** Configures the WEP key. It defines a WEP key to a specific SSID.

**Command Syntax:** **configure privacy wep ssid <index number> index <key index> {40 | 104} <key hex>**

**Command Description:**

Parameter	Value
index number	SSID index number. 1-8
key index	Defines the WEP key index number. 1-4 In this version the index number is always set to 1.
40   104	Defines the length of the WEP key: 40 – 40 bit key 104 – 104 bit key
key hex	For a 40 bit key specify a 5 octet string in hexadecimal format. (Example: 01:23:45:67:89) For a 104 bit key specify a 13 octet string in hexadecimal format. (Example: 01:23:45:67:89:01:23:45:67:89:01:23:45)

**Example:** configure privacy wep ssid 3 index 1 40 01:23:45:67:89

**Permission Level:** admin

**Related Commands:**

configure privacy wep ssid default-key  
 configure ssid  
 show ssid params  
 show privacy wep  
 show privacy wep params

## CONFIGURE PRIVACY WPA

**Function:** Configures the WPA privacy for a specific SSID.

**Command Syntax:** **configure privacy wpa ssid <ssid index> [passphrase <passphrase string>] [key-mngmnt {eap | psk}]  
**configure privacy wpa** gtk-interval <interval number>  
**configure privacy wpa** data-encryption {tkip | aes | both}  
**configure privacy wpa** protocol {wpa1 | wpa2 | wpa2only}  
**configure privacy wpa** preauthentication {enable | disable}**

**Command Description:**

Parameter	Value
ssid index	An existing SSID index number: 1-8
passphrase string	Defines the passphrase used during the key handshake process for WPA encryption. The value is case sensitive and can be from 8 to 63 characters.
eap   psk   both	Defines the key management type: eap – Extended Authorization Protocol

---

	psk – Pre-Shared Key both – Enables both AES and TKIP
interval number	Defines the GTK (Group Temporal Key) interval in seconds. It defines the time interval the unit initiates a GTK change. 30-42949672 The default value is 3600 (1 hour).
tkip   aes	Defines the data encryption type: tkip – Temporary Key Integrity Protocol aes – Advanced Encryption Standard (AES/CCMP) The default value is tkip.
wpa1   wpa2   wpa2only	Defines the WPA protocol type: wpa1 – Supports WPA1 only. wpa2 – Supports WPA1 and WPA2. wpa2only – Supports WPA2 only, without support for WPA1. The default value is wpa2.
enable   disable	WPA2 Preauthentication: enable – Enables WPA2 Preauthentication disable – Disables WPA2 Preauthentication The default value is disable. To enable WPA2 Preauthentication, the WPA protocol must support WPA2.

---

**Example:** configure privacy wpa ssid 1 key-mngmnt psk

**Permission Level:** admin

**Related Commands:**

show privacy wpa

## CONFIGURE RADIUS

**Function:** Configures communications with the Radius server. This command is used to configure the parameters required to communicate with the primary and the secondary Radius servers. For each server the authentication and accounting parameters can be configured to permit access to the Radius servers.  
The accounting services monitors and records the number of packets transmitted and received by each authenticated client.  
To implement Radius server services the WPA-EAP security must be configured.

**Command Syntax:**

```
configure radius {accounting | authentication} ssid <ssid index> priority <priority number> [host <address ipaddress>] [port <port number>] key <secret string>
configure radius {accounting | authentication} ssid <ssid index> priority <priority number> remove
```

**Command Description:**

Parameter	Value
authentication   accounting	authentication – Configures parameters to communicate with the authentication services on the Radius server. accounting – Configures parameters to communicate with the accounting services on the Radius server.
ssid index	An existing SSID index number: 1-8
priority number	Defines the priority of the radius servers: 1 – Configures the parameters to communicate with the primary Radius server. 2 – Configures parameters to communicate with the secondary Radius server.
port number	Number of the authentication or accounting port on the Radius server: 1-65535 This parameter is optional. The default value for authentication port is 1812. The default value for accounting port is 1813.
address ipaddress	IP address of the authentication or accounting Radius server.
secret string	Defines the key used for Radius server security. The value is case sensitive and can be from 5 to 63 characters.
Remove	Removes the specified Radius server.

**Example:**      `configure radius authentication ssid 1 priority 1 host 192.168.0.1 key Netronics-NPP`

**Permission Level:**    super

**Related Commands:**

<code>configure privacy wpa</code>	<code>configure radius retry-primary-interval</code>
<code>configure radius interim-interval</code>	<code>show privacy wpa</code>
	<code>show radius</code>

## CONFIGURE RADIUS INTERIM-INTERVAL

**Function:**                Defines the frequency that the unit sends accounting updates to the Radius server.

**Command Syntax:**      `configure radius interim-interval <interval number>`

**Command Description:**

Parameter	Value
interval number	Defines the time interval that the unit waits between sending accounting updates to the Radius server (seconds). 1 – 42949672 The default value is 600 seconds (10 minutes).

**Example:**      `configure radius interim-interval 1200`

**Permission Level:**    super

**Related Commands:**

<code>configure radius</code>
<code>show radius</code>

## CONFIGURE RADIUS RETRY-PRIMARY-INTERVAL

**Function:** After switching to the secondary Radius server, this configures the time interval, in seconds, that the unit waits before retrying to use the primary Radius server again.

**Command Syntax:** `configure radius retry-primary-interval <interval number>`

**Command Description:**

Parameter	Value
interval number	Defines the time interval that the unit waits before trying to use the primary Radius server (seconds). 1 – 42949672 The default value is 900 seconds (15 minutes).

**Example:** `configure radius retry-primary-interval 1200`

**Permission Level:** super

**Related Commands:**

`configure radius`  
`show radius`

## CONFIGURE RECOVERY-SSID

**Function:** Enables and disables the recovery SSID mode.

**Command Syntax:** `configure recovery-ssid {enable | disable}`

**Command Description:**

Parameter	Value
enable   disable	enable – Enables the recovery SSID mode. Enables Dot11Radio 0 disable – Disables the recovery SSID mode. The default mode is enable.

**Example:** `configure recovery-ssid enable`

**Permission Level:** admin

**Related Commands:**

`show recovery-ssid status`

## CONFIGURE SITESURVEY

**Function:** Performs a site survey of all available channels, for the selected spectrum. When a site survey is performed all services from the unit are disrupted and the unit proceeds to scan each available channel.

The site survey scans each channel to determine the interference level of all available channels. To display the test results, use the `show sitesurvey` command. These results can then be used to assist you in selecting the best available channel.

**Command Syntax:** `configure sitesurvey start spectrum {all | 80211bg | 80211a} auto-channel-selection {enable | disable}`

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.
all   80211bg   80211a	Defines the frequency spectrum for the site survey: all – Performs the site survey on both frequency spectrums. 80211bg – Performs the site survey on the 80211bg spectrum (2.4GHz). 80211a – Performs the site survey on the 80211a spectrum (5GHz).
enable   disable	enable – Enables the automatic channel selection. disable – Disables the automatic channel selection.

**Example:** `configure sitesurvey start spectrum all auto-channel-selection enable`

**Permission Level:** super

**Related Commands:**

`configure interface Dot11Radio channel`  
`configure interface Dot11Radio channel-list`  
`show interface Dot11Radio`  
`show interface Dot11Radio params`  
`show interface Dot11Radio channel-list`  
`show sitesurvey`

## CONFIGURE SNMP ROCOMMUNITY

**Function:** Configures the SNMP read-only community name.

**Command Syntax:** `configure snmp rocommunity <rocommunity name>`

**Command Description:**

Parameter	Value
rocommunity name	Read-only community name. The value is case sensitive and can be up to 32 characters. The default value is public.

**Example:** `configure snmp rocommunity public`

**Permission Level:** admin

**Related Commands:**

`configure snmp rwcommunity`  
`show snmp-communities`

## CONFIGURE SNMP RWCOMMUNITY

**Function:** Configures the SNMP read and write community name.

**Command Syntax:** **configure snmp rwcommunity <rwcommunity name>**

**Command Description:**

Parameter	Value
rwcommunity name	Read and write community name. The value is case sensitive and can be up to 32 characters. The default value is private.

**Example:** configure snmp rwcommunity private

**Permission Level:** admin

**Related Commands:**

configure snmp rocommunity  
show snmp-communities

## CONFIGURE SSID

**Function:** Configures the SSID. This command is used to create or define a unique SSID. Once created, this SSID can be shared on all devices that belong to your wireless network. Use the *configure ssid remove* command to remove an existing SSID.

**Command Syntax:** **configure ssid <index number> name <ssid string> vlan <vlan number> privacy-method {none | wep | wpa} type {hidden | bssid}**

**Command Description:**

Parameter	Value
index number	SSID index number: 1-8
ssid string	A string value that defines the name of the SSID. The value can be up to 32 characters. It can contain alpha-numeric chars [a-z,A-Z,0-9], '-', '_', and '.'. Spaces may also be used, but the SSID name must be contained in quotation marks.
vlan number	VLAN index number: 0-4095 Set the value to 0 to specify no VLAN tagging.
none   wep   wpa	Defines the basic privacy method of this SSID: none – No privacy wep – WEP privacy wpa – WPA privacy Use the <i>configure privacy</i> command for additional privacy configuration options.
hidden   bssid	Defines the SSID type: hidden – Hidden SSID. Does not transmit beacons. bssid – Transmits beacons.

**Example:**

This example demonstrates how to configure an SSID with the following parameters:  
SSID name = NPP-1  
SSID name = BSSID  
VLAN ID = 0 (no VLAN tagging)  
Privacy method = none

```

SSID TC profile name = TcProfile75M
User TC profile name = TcProfile3M
configure ssid 1 name NPP-1 vlan 0 privacy-method none type bssid ssid-
profile TcProfile75M user-profile TcProfile3M

```

**Permission Level:** admin

**Related Commands:**

configure privacy wep ssid index	configure privacy wpa
configure ssid remove	configure tc-default-profile
configure tc-profile modify	configure tc-profile new
configure tc-profile remove	show interface ssids
show ssid params	show tc-default-profile
show tc-profiles	show privacy wep
show privacy wpa	

## CONFIGURE SSID FORCED-ROUTING

**Function:** Configures the forced-routing mode. When enabled, all communications between clients, including clients with the same VLAN or SSID, are routed through the specified router.

**Command Syntax:** **configure ssid <index number> forced-routing [{enable | disable}] [ip <ipaddress>]**

**Command Description:**

Parameter	Value
index number	SSID index number. 1-8
enable   disable	enable – Enables forced routing. disable – Disables forced routing. This parameter is optional. The default value is disable.
ipaddress	IP address of the target when the forced-routing mode is enabled. This parameter is optional.

**Example:** configure ssid 1 forced-routing enable ip 192.168.250.1

**Permission Level:** admin

**Related Commands:**

show ssid forced-routing  
show ssid params

## CONFIGURE SSID MACFILTER

**Function:** Configures or removes a MAC Filter for an existing SSID.

**Command Syntax:** **configure ssid <index number> macfilter <mac-filter-index number>**  
**configure ssid <index number> macfilter remove**

**Command Description:**

Parameter	Value
index number	SSID index number. 1-8
mac-filter-index number	MAC Filter List index number. 1-16
remove	Removes the MAC Filter for an existing SSID.

**Example:** configure ssid 1 macfilter 5

**Permission Level:** admin

**Related Commands:**

show mac-filter indices  
show mac-filter list

**CONFIGURE SSID PRIVACY-METHOD**

**Function:** Modifies the privacy method for an existing SSID.

**Command Syntax:** **configure ssid <index number> privacy-method {none | wep | wpa}**

**Command Description:**

Parameter	Value
index number	SSID index number. 1-8
none   wep   wpa	Defines the basic privacy method of this SSID. none – No privacy wep – WEP privacy wpa – WPA privacy <i>Use the <i>configure privacy</i> command for additional privacy configuration options.</i>

**Example:** configure ssid 1 privacy-method none

**Permission Level:** admin

**Related Commands:**

configure ssid  
configure privacy wep ssid index  
configure privacy wpa  
show ssid params  
show privacy wep  
show privacy wpa

**CONFIGURE SSID REMOVE**

**Function:** Deletes the specified SSID.

**Command Syntax:** **configure ssid <index number> remove**

**Command Description:**

Parameter	Value
index number	SSID index number. 1-8

**Example:** configure ssid 1 remove

**Permission Level:** admin

**Related Commands:**

configure ssid  
 configure privacy wpa  
 configure privacy wep ssid index  
 show ssid params  
 show privacy wep  
 show privacy wpa

**CONFIGURE SSID RENAME**

**Function:** Renames an existing SSID.

**Command Syntax:** **configure ssid <index number> rename <ssid string>**

**Command Description:**

Parameter	Value
index number	SSID index number. 1-8
ssid string	A string value that defines the name of the SSID. The value can be up to 32 characters. It can contain alpha-numeric chars [a-z,A-Z,0-9], '_', '_', and '!'. Spaces may also be used, but the SSID name must be contained in quotation marks.

**Example:** configure ssid 1 rename NPP-2

**Permission Level:** admin

**Related Commands:**

configure ssid  
 configure privacy wep ssid index  
 configure privacy wpa  
 show ssid params  
 show privacy wep  
 show privacy wpa

**CONFIGURE SSID SSID-PROFILE**

**Function:** Modifies the assigned SSID TC profile for an existing SSID. This profile is used to define the maximum throughput for the specified SSID for each device. It limits the total traffic for all connected stations.

**Command Syntax:** `configure ssid <index number> ssid-profile <ssid profile name>`

**Command Description:**

Parameter	Value
index number	SSID index number. 1-8
ssid profile name	Defines the assigned SSID TC profile. Specify the name of an existing Traffic Control profile. The value is case sensitive and can be up to 32 characters.

**Example:** `configure ssid 1 ssid-profile TcProfile75M`

**Permission Level:** admin

**Related Commands:**

configure ssid  
 configure privacy wep ssid index  
 configure privacy wpa  
 configure ssid remove  
 configure tc-default-profile  
 configure tc-profile modify  
 configure tc-profile new  
 configure tc-profile remove  
 show interface ssids  
 show ssid params  
 show tc-default-profile  
 show tc-profiles  
 show privacy wep  
 show privacy wpa

## CONFIGURE SSID TYPE

**Function:** Redefines the SSID type for an existing SSID.

**Command Syntax:** `configure ssid <index number> type {hidden | bssid}`

**Command Description:**

Parameter	Value
index number	SSID index number. 1-8
hidden   bssid	Defines the SSID type: hidden – Hidden SSID. Does not transmit beacons. bssid – Transmits beacons.

**Example:** `configure ssid 1 type bssid`

**Permission Level:** admin

**Related Commands:**

```
configure ssid; show privacy wpa  
configure privacy wep ssid index  
configure privacy wpa  
show ssid params  
show privacy wep
```

## CONFIGURE SSID USER-PROFILE

**Function:** Modifies the assigned User TC profile for an existing SSID. This profile is used to define the maximum throughput for each user for the specified SSID.

**Command Syntax:** `configure ssid <index number> user-profile <user profile name>`

**Command Description:**

Parameter	Value
index number	SSID index number. 1-8
user profile name	Defines the assigned User TC profile. Specify the name of an existing Traffic Control profile. The value is case sensitive and can be up to 32 characters.

**Example:** `configure ssid 1 user-profile TcProfile3M`

**Permission Level:** admin

**Related Commands:**

```
configure ssid  
configure privacy wep ssid index  
configure privacy wpa  
configure ssid remove  
configure tc-default-profile  
configure tc-profile modify  
configure tc-profile new  
configure tc-profile remove  
show interface ssids  
show ssid params  
show tc-default-profile  
show tc-profiles  
show privacy wep  
show privacy wpa
```

## CONFIGURE SSID VLAN

**Function:** Modifies the VLAN index for an existing SSID.

**Command Syntax:** `configure ssid <index number> vlan <vlan number>`

**Command Description:**

Parameter	Value
index number	SSID index number. 1-8
vlan number	VLAN index number. 0-4095 Set the value to 0 to specify no VLAN tagging.

**Example:** configure ssid 1 vlan 0

**Permission Level:** admin

**Related Commands:**

configure ssid  
 configure privacy wep ssid index  
 configure privacy wpa  
 show ssid params  
 show privacy wep  
 show privacy wpa

## CONFIGURE TC

**Function:** Configures the Traffic Control operation mode.

**Command Syntax:** **configure tc {enabled | disabled | on | off}**

**Command Description:**

Parameter	Value
enabled   disabled   on   off	enabled – Enables the Traffic Control operation mode. disabled – Disables the Traffic Control operation mode. on – Enables the Traffic Control controller. Changes are implemented after restarting the unit. off – Disables the Traffic Control controller. Changes are implemented after restarting the unit. The default mode is disabled and off.

**Example:** configure tc enabled

**Permission Level:** admin

**Related Commands:**

configure tc-default-profile  
 configure tc-profile modify  
 configure tc-profile new  
 configure tc-profile remove  
 show tc-default-profile  
 show tc-profiles

## CONFIGURE TC-DEFAULT-PROFILE

**Function:** Defines which Traffic Control profile is the system default profile. This profile is the default profile that is assigned to SSIDs. It is used to define maximum throughput. To display the existing default profile, use the *show tc-default-profile* command. To display all existing Traffic Control profiles, use the *show tc-profile* command.

**Command Syntax:** **configure tc-default-profile <profile name>**

**Command Description:**

Parameter	Value
profile name	The name of an existing Traffic Control profile to be defined as the system default Traffic Control profile. The value is case sensitive and can be up to 32 characters.

**Example:** **configure tc-default-profile profile75Mbps**

**Permission Level:** admin

**Related Commands:**

configure ssid  
 configure tc  
 configure tc-profile modify  
 configure tc-profile new  
 configure tc-profile remove  
 show tc-default-profile  
 show tc-profiles

## CONFIGURE TC-PROFILE MODIFY

**Function:** Modifies an existing Traffic Control profile. These profiles are used in configuring SSIDs to define maximum throughput.

**Command Syntax:** **configure tc-profile <profile name> modify [max-download <maxd1>] [max-upload <maxu1>]**

**Command Description:**

Parameter	Value
profile name	A string value that defines the name of an existing Traffic Control profile. The value is case sensitive and can be up to 32 characters.
maxdl	Maximum download throughput (kbits/s): 1-100000 This parameter is optional.
maxul	Maximum upload throughput (kbits/s): 1-54000 This parameter is optional.

**Example:** configure tc-profile TcProfile2 modify max-download 45000

**Permission Level:** admin

**Related Commands:**

configure ssid  
configure tc  
configure tc-default-profile  
configure tc-profile new  
configure tc-profile remove  
show tc-default-profile  
show tc-profiles

## CONFIGURE TC-PROFILE NEW

**Function:** Creates a new Traffic Control profile. These profiles are used in configuring SSIDs to define maximum throughput. To implement a Traffic Control profile, the profile can be set as the default Traffic Control profile or be assigned to an SSID. To define the default Traffic Control profile, use the *configure tc-default-profile* command. To assign a profile to an SSID, use the *configure ssid* command.

**Command Syntax:** **configure tc-profile <profile name> new max download <maxd1> upload <maxu1>**

**Command Description:**

Parameter	Value
profile name	A string value that defines the name of the new Traffic Control profile. The value is case sensitive and can be up to 32 characters.
maxdl	Maximum download throughput (kbits/s): 1-100000
maxul	Maximum upload throughput (kbits/s): 1-54000

**Example:** configure tc-profile profile50Mbps new max download 50000 upload 50000

**Permission Level:** admin

**Related Commands:**

configure ssid  
configure tc  
configure tc-default-profile  
configure tc-profile modify  
configure tc-profile remove  
show tc-default-profile  
show tc-profiles

## CONFIGURE TC-PROFILE REMOVE

**Function:** Deletes an existing Traffic Control profile. If a Traffic Control profile is currently assigned to an SSID, another profile must first be assigned to the SSID before deleting. To assign a different profile to an SSID, use the *configure ssid* command.

**Command Syntax:** `configure tc-profile <profile name> remove`

**Command Description:**

Parameter	Value
profile name	A string value that defines the name of an existing Traffic Control profile. The value is case sensitive and can be up to 32 characters.

**Example:** `configure tc-profile profile75Mbps remove`

**Permission Level:** admin

**Related Commands:**

`configure ssid`  
`configure tc`  
`configure tc-default-profile`  
`configure tc-profile modify`  
`configure tc-profile new`  
`show tc-default-profile`  
`show tc-profiles`

## CONFIGURE TRAP-NOTIFY-FILTER

**Function:** Defines the type of traps that are sent to the trap targets. By default, all types of traps are sent to the trap targets. To display the current settings of the trap filter, use the *show trap-notify-filters* command.

**Command Syntax:** `configure trap-notify-filter category <category> {enable | disable}`

**Command Description:**

Parameter	Value
category	Defines the type of traps that are sent to the trap targets: boot – Defines whether the boot category traps are sent interface – Defines whether the interface category traps are sent system – Defines whether the system category traps are sent operation – Defines whether the operations category traps are sent configuration – Defines whether the configuration category traps are sent cli – Defines whether the CLI category traps are sent aaa – Defines whether the radius category traps are sent sm – Defines whether the sm category traps are sent mesh – Defines whether the Mesh category traps are sent sta – Defines whether the station category traps are sent wifi – Defines whether the Wi-Fi category traps are sent
enable   disable	enable – The specified trap category is sent to the trap targets. disable – The specified trap category is not sent to the trap targets. The default value is enable for all trap categories except for the station category (sta).

**Example:** configure trap-notify-filter category sta enable

**Permission Level:** super

**Related Commands:**

configure trap-target add  
 configure trap-target remove  
 show trap-notify-filters  
 show trap-targets

## CONFIGURE TRAP-TARGET ADD

**Function:** Adds a configuration definition for sending traps. To define the type of traps that will be sent to the trap targets, use the *configure trap-notify-filter* command.

**Command Syntax:** **configure trap-target add <name> <ip address> [port <port number> [retry-count <retry-count>] [timeout <timeout>] [security-name <security-name>]**

**Command Description:**

Parameter	Value
name	Name of the trap configuration definition.
ip address	IP address of the destination for the trap.
port number	Number of the port to which the trap is sent: 1-65535 This parameter is optional. The default value is 162.
retry-count	Number of retries to communicate with the target. This parameter is optional. The default value is 3.
timeout	Time in msec the unit waits for a response from the target. This parameter is optional. The default value is 1500 (1500 msec).
security-name	Community name that must match between the target and the unit. The default value is private.

**Example:** configure trap-target add nms 192.168.0.1

**Permission Level:** super

**Related Commands:**

configure trap-notify-filter  
 configure trap-target remove  
 show trap-notify-filters  
 show trap-targets

## CONFIGURE TRAP-TARGET REMOVE

**Function:** Removes a configuration definition for sending traps.

**Command Syntax:** **configure trap-target remove <name>**

**Command Description:**

Parameter	Value
name	Name of the trap configuration definition.

**Example:** configure trap-target remove nms

**Permission Level:** super

**Related Commands:**

configure trap-notify-filter  
 configure trap-target add  
 show trap-notify-filters  
 show trap-targets

**CONFIGURE USERNAME**

**Function:** Configures the local CLI users.

**Command Syntax:** **configure username <username string>** delete  
**configure username <username string>** {password <password string> | encrypted-password <encrypted-password string> | nopassword} privilege {super | admin | viewer}

**Command Description:**

Parameter	Value
username string	Name of the CLI user to be configured. The value is case sensitive and can be up to 32 characters.
delete	Deletes the specified CLI user.
password   encrypted-password   nopassword	Password types: password – Defines a CLI non-encrypted user password. encrypted-password – Defines a CLI user with an encrypted password. nopassword – Defines a CLI user without a password.
password string	A string value that defines the password for a non-encrypted password. The value is case sensitive and can be up to 32 characters.
encrypted-password string	A string value that defines the password for an encrypted password. The value is the hashing result of the actual password and this result is 32 characters.
super   admin   viewer	CLI user privilege level: viewer – Low privileges admin – Medium privileges super – High privileges

**Example:** configure username guest nopassword privilege viewer

**Permission Level:** super

**Related Commands:**

configure username modify  
 show default-config

show running-config  
show startup-config  
show users

## CONFIGURE USERNAME MODIFY

**Function:** Modifies an existing local CLI user.

**Command Syntax:** **configure username <username string> modify {password <password string> | encrypted-password <encrypted-password string> | nopassword}**

**Command Description:**

Parameter	Value
username string	Name of the existing CLI user to be configured. The value is case sensitive and can be up to 32 characters.
password   encrypted-password   nopassword	Password types: password – Defines a CLI non-encrypted user password. encrypted-password – Defines a CLI user with an encrypted password. nopassword – Defines a CLI user without a password.
password string	A string value that defines the password for a non-encrypted password. The value is case sensitive and can be up to 32 characters.
encrypted-password string	A string value that defines the password for an encrypted password. The value is the hashing result of the actual password and this result is 32 characters.

**Example:** configure username guest modify nopassword

**Permission Level:** super

**Related Commands:**

configure username  
show default-config  
show running-config  
show startup-config  
show users

## CONFIGURE WEB

**Function:** Enables and disables the web service.

**Command Syntax:** **configure web {enable | disable}**

**Command Description:**

Parameter	Value
enable   disable	enable – Enables the web service disable – Disables the web service. The default mode is enable.

**Example:** configure web enable

**Permission Level:** super

**Related Commands:**

show web status

## COPY RUNNING-CONFIG STARTUP-CONFIG

**Function:** Copies the currently running configuration and replaces the existing startup configuration. The startup configuration is saved in non-volatile memory and is used when starting the unit.

**Command Syntax:** `copy running-config startup-config`

**Command Description:**

Parameter	Value
None	

**Example:** `copy running-config startup-config`

**Permission Level:** super

**Related Commands:**

show running-config  
show startup-config

## DELETE STARTUP-CONFIG

**Function:** Deletes the current startup configuration and uses the default configuration after restarting the unit. After a restart, all changes made to the configuration of this unit will be lost.

**Command Syntax:** `delete startup-config`

**Command Description:**

Parameter	Value
None	

**Example:** `delete startup-config`

**Permission Level:** super

**Related Commands:**

reload  
show messages

## DISASSOCIATE-STA

**Function:** Disconnects communications with the specified station.

**Command Syntax:** `disassociate-sta <macaddr>`

**Command Description:**

Parameter	Value
macaddr	MAC address of the station to be disconnected.

**Example:** `disassociate-sta 00:14:06:11:00:00`

**Permission Level:** super

**Related Commands:**

None

## EXPORT STARTUP-CONFIG

**Function:** Exports the startup configuration to the TFTP server. The startup configuration is saved in non-volatile memory and is used when starting the unit.

**Command Syntax:** `export startup-config to tftp <server ipaddress> <filename string>`

**Command Description:**

Parameter	Value
server ipaddress	IP address of the TFTP server.
filename string	A string value that defines the name of the file that will be saved on the TFTP server. The value can be up to 128 characters.

**Example:** `export startup-config to tftp 192.168.0.1 wls_config.txt`

**Permission Level:** super

**Related Commands:**

`import startup-config`  
`show startup-config`

## EXPORT SYSTEM-BACKUP

**Function:** Exports the entire system configuration to the TFTP server.

**Command Syntax:** `export system-backup to tftp <server ipaddress> <filename string>`

**Command Description:**

Parameter	Value
server ipaddress	IP address of the TFTP server.
filename string	A string value that defines the name of the file that will be saved on the TFTP server. The value can be up to 128 characters.

**Example:** export system-backup to tftp 192.168.0.1 wls\_config.txt

**Permission Level:** super

**Related Commands:**

None

## HOSTNAME

**Function:** Defines a new CLI prompt.

**Command Syntax:** **hostname <prompt string>**

**Command Description:**

Parameter	Value
prompt string	String value defining the new CLI prompt. This value is case sensitive.

**Example:** hostname Netronics

**Permission Level:** admin

**Related Commands:**

none

## IMPORT IMAGE

**Function:** Imports the firmware from the TFTP server. The TFTP server can be specified by either its IP address and filename, or its URL. To implement the new firmware, restart the unit.

**Command Syntax:** **import image from {{tftp <ip> <filename string>} | {url <url string>}}**

**Command Description:**

Parameter	Value
ip	IP address of the TFTP server.
filename string	A string value that defines the name of the software image file. The value can be up to 128 characters.
url string	A string value that defines the full url to the software image file. The value can be up to 128 characters.

**Example:** import image from tftp 192.168.0.1 gapsw-2.2.20.16836-Beta-13.11.2006@172953.img

**Permission Level:** super

**Related Commands:**

show version  
 show messages  
 show softload-messages

**IMPORT STARTUP-CONFIG**

**Function:** Imports the startup configuration from the TFTP server and replaces the existing startup configuration in the unit. The startup configuration is saved in non-volatile memory and is used when starting the unit.

**Command Syntax:** **import startup-config from tftp <ip address> <filename string>**

**Command Description:**

Parameter	Value
ip address	IP address of the TFTP server.
filename string	A string value that defines the name of the file to be downloaded. The value can be up to 128 characters.

**Example:** import startup-config from tftp 192.168.0.1 wls\_config.txt

**Permission Level:** super

**Related Commands:**

show startup-config

**IPRF-CLIENT**

**Function:** Configures the Iperf client. The Iperf client is used to run performance tests of the network between this unit and the specified Iperf server.

**Command Syntax:** **iprf-client restart {udp | tcp} <server ip-address> <timeout>**  
**iprf-client status**  
**iprf-client stop**

**Command Description:**

Parameter	Value
restart   status   stop	restart – Starts a new Iperf session and displays the performance test results. status – Displays the current status of the Iperf client. stop – Stops the Iperf client.
udp   tcp	udp – Iperf client uses UDP packets. tcp – Iperf client uses TCP packets.
server ip-address	IP address of the Iperf server
timeout	Time period of the performance test in seconds.

**Example:** iprf-client restart udp 192.168.0.1 90

**Permission Level:** super

**Related Commands:**

iprf-server

**IPRF-SERVER**

**Function:** Configures the Iperf server. This server is used to test the throughput between this unit and its connected Iperf clients. Once the current telnet session is closed the Iperf server is terminated. To perform a long test the CLI timeout must be configured to a longer period of time.

**Command Syntax:** **iprf-server** restart {udp | tcp} [<timeout>]  
**iprf-server** status  
**iprf-server** stop

**Command Description:**

Parameter	Value
restart   status   stop	restart – Starts a new Iperf session. status – Displays the current status of the Iperf server. stop – Stops the Iperf server.
udp   tcp	udp – Iperf server uses UDP packets. tcp – Iperf server uses TCP packets.
timeout	Time period of the performance test in seconds. This parameter is optional.

**Example:** iprf-server restart udp

**Permission Level:** super

**Related Commands:**

configure inactivity-timeout  
iprf-client

**MORE**

**Function:** Enables or disables the **more** display option. When this is enabled, the first page is displayed for large outputs and then pauses. Press SPACEBAR to display the next page or press ENTER to display the next line.

**Command Syntax:** **more** {enable | disable}

**Command Description:**

Parameter	Value
enable   disable	enable – Enables the <b>more</b> display option. disable – Disables the <b>more</b> display option. The default value is enabled.

**Example:** more disable

**Permission Level:** viewer

**Related Commands:**

None

## PING

**Function:** Sends ICMP ping packets to the specified IP address.

**Command Syntax:** `ping <dest ip-address>`

**Command Description:**

Parameter	Value
dest ip-address	IP address for the ping destination.

**Example:** `ping 192.168.0.1`

**Permission Level:** admin

**Related Commands:**

None

## RELOAD

**Function:** Reboots the system.

**Command Syntax:** `reload [{bank1 | bank2}]`

**Command Description:**

Parameter	Value
bank1   bank2	bank1 – Reboots from software bank 1. bank2 – Reboots from software bank 2. This parameter is optional.

**Example:** `reload`

**Permission Level:** admin

**Related Commands:**

`show uptime`

## SHOW ASSOCIATED-STATIONS

**Function:** Displays the MAC addresses of the clients connected to each radio interface.

**Command Syntax:** show associated-stations

**Command Description:**

Parameter	Value
None	

**Example:** show associated-stations

**Related Commands:**

show spectrum-management clear-count-percent  
show spectrum-management doa

## SHOW CAC ACTIVE-VOIP-CLIENTS

**Function:** Displays all active VoIP clients.

**Command Syntax:** show cac active-voip-clients

**Command Description:**

Parameter	Value
None	

**Example:** show cac active-voip-clients

**Permission Level:** viewer

**Related Commands:**

configure cac  
configure cac min-vc-snr  
show cac params

## SHOW CAC MAC\_CLASSIFIER\_MASKS

**Function:** Displays all active MAC masks for VoIP.

**Command Syntax:** show cac mac\_classifier\_masks

**Command Description:**

Parameter	Value
None	

**Example:** show cac mac\_classifier\_masks

**Permission Level:** viewer

**Related Commands:**

configure cac

configure cac algorithm  
configure cac mac\_classifier  
configure cac min-vc-snr  
show cac active-voip-clients

## SHOW CAC PARAMS

**Function:** Displays the current CAC configuration.

**Command Syntax:** **show cac params**

**Command Description:**

Parameter	Value
None	

**Example:** show cac params

**Permission Level:** viewer

**Related Commands:**

configure cac  
configure cac algorithm  
configure cac mac\_classifier  
configure cac min-vc-snr  
show cac active-voip-clients

## SHOW CALIBRATION STATUS

**Function:** Displays the calibration status of the radio interface channels.

**Command Syntax:** **show calibration status**

**Command Description:**

Parameter	Value
None	

**Example:** show calibration status

**Permission Level:** super

**Related Commands:**

configure interface Dot11Radio channel

## SHOW CLASSIFIER

**Function:** Displays a table containing all the codecs currently in the classifier and the configuration for these codecs.

**Command Syntax:** **show classifier**

**Command Description:**

Parameter	Value
None	

**Example:** **show classifier**

**Permission Level:** viewer

**Related Commands:**

configure classifier

configure classifier add

configure classifier remove

## SHOW COUNTRY-CODE

**Function:** Displays the current country code.

**Command Syntax:** **show country-code**

**Command Description:**

Parameter	Value
None	

**Example:** **show country-code**

**Permission Level:** admin

**Related Commands:**

None

## SHOW DEFAULT-CONFIG

**Function:** Displays the default configuration of the unit. This configuration contains the factory settings.

**Command Syntax:** **show default-config**

**Command Description:**

Parameter	Value
None	

**Example:** show default-config

**Permission Level:** admin

**Related Commands:**

import startup-config  
delete startup-config

## SHOW ENHANCED-OMNI

**Function:** Displays the current status of the enhanced omni mode.

**Command Syntax:** **show enhanced-omni**

**Command Description:**

Parameter	Value
None	

**Example:** show enhanced-omni

**Permission Level:** admin

**Related Commands:**

configure enhanced-omni

## SHOW INACTIVITY-TIMEOUT

**Function:** Displays the CLI inactivity time-out. The time displayed is the time that the CLI will automatically log off the user when the user's session is not active.

**Command Syntax:** **show inactivity-timeout**

**Command Description:**

Parameter	Value
None	

**Example:** show inactivity-timeout

**Permission Level:** viewer

**Related Commands:**

configure inactivity-timeout

## SHOW INTERFACE DOT11RADIO

**Function:** Displays the typical parameter settings of the specified interface or all radio interfaces.

**Command Syntax:** `show interface Dot11Radio [<interface number>]`

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications. This parameter is optional. If not specified, the typical parameter settings for all radio interfaces are displayed.

**Example:** `show interface Dot11Radio 0`

**Permission Level:** viewer

**Related Commands:**

`configure interface Dot11Radio disable`  
`configure interface Dot11Radio enable`  
`configure interface Dot11Radio beacon-period`  
`configure interface Dot11Radio beacon-rate`  
`configure interface Dot11Radio channel`  
`configure interface Dot11Radio dtim-period`  
`configure interface Dot11Radio mode`  
`configure interface Dot11Radio service`

## SHOW INTERFACE DOT11RADIO CHANNEL-LIST

**Function:** Displays all the Wi-Fi channels available and allowable for the specified radio interface or all radio interfaces.

**Command Syntax:** `show interface Dot11Radio [<interface number>] channel-list`

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications. This parameter is optional. If not specified, the channel list for all radio interfaces is displayed.

**Example:** `show interface Dot11Radio 0 channel-list`

**Permission Level:** admin

**Related Commands:**

`configure interface Dot11Radio channel`

configure interface Dot11Radio channel-list

## SHOW INTERFACE DOT11RADIO MESH-SCAN-RESULTS

**Function:** Displays the results of the latest channel scan.

To perform a channel scan, use the *configure sitesurvey* command.

**Command Syntax:** **show interface Dot11Radio <interface number> mesh-scan-results**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications. This parameter is optional. If not specified, the channel list for all radio interfaces is displayed.

**Example:** show interface Dot11Radio 0 mesh-scan-results

**Permission Level:** admin

**Related Commands:**

configure interface Dot11Radio channel  
 configure interface Dot11Radio channel-list  
 configure sitesurvey  
 show interface Dot11Radio channel-list

## SHOW INTERFACE DOT11RADIO PARAMS

**Function:** Displays the configuration of the specified interface or all radio interfaces.

**Command Syntax:** **show interface Dot11Radio [<interface number>] params**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications. This parameter is optional. If not specified, the configurations for all radio interfaces are displayed.

**Example:** show interface Dot11Radio 0 params

**Permission Level:** viewer

**Related Commands:**

configure interface Dot11Radio disable

configure interface Dot11Radio enable  
 configure interface Dot11Radio beacon-period  
 configure interface Dot11Radio beacon-rate  
 configure interface Dot11Radio channel  
 configure interface Dot11Radio dtim-period  
 configure interface Dot11Radio erp-mode  
 configure interface Dot11Radio fixed-rate  
 configure interface Dot11Radio max-assoc  
 configure interface Dot11Radio max-rate  
 configure interface Dot11Radio min-rate  
 configure interface Dot11Radio mode  
 configure interface Dot11Radio preamble-mode  
 configure interface Dot11Radio rts  
 configure interface Dot11Radio sensitivity  
 configure interface Dot11Radio service  
 configure interface Dot11Radio wme-enable

## SHOW INTERFACE DOT11RADIO PROFILE

**Function:** Displays the current profile parameters for the specified radio interface or all radio interfaces.

**Command Syntax:** `show interface Dot11Radio [<interface number>] profile`

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications. This parameter is optional. If not specified, the profile parameters for all radio interfaces are displayed.

**Example:** `show interface Dot11Radio 0 profile`

**Permission Level:** super

**Related Commands:**

configure interface Dot11Radio profile  
 configure interface Dot11Radio wme  
 configure interface Dot11Radio wme-enable  
 show interface Dot11Radio params  
 show interface Dot11Radio wme

## SHOW INTERFACE DOT11RADIO RANGE-OPTIMIZATION

**Function:** Displays the type of optimization that is currently implemented for the calibration of the RX sensitivity on the specified radio interface.

**Command Syntax:** `show interface Dot11Radio <interface number> range-optimization`

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications.

**Example:** show interface Dot11Radio 0 range-optimization

**Permission Level:** super

**Related Commands:**

configure interface Dot11Radio range-optimization

**SHOW INTERFACE DOT11RADIO STATS**

**Function:** Displays the statistics of the specified interface or all radio interfaces.

**Command Syntax:** **show interface Dot11Radio [<interface number>] stats**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications. This parameter is optional. If not specified, the statistics for all radio interfaces are displayed.

**Example:** show interface Dot11Radio 0 stats

**Permission Level:** viewer

**Related Commands:**

configure interface Dot11Radio disable

configure interface Dot11Radio enable

**SHOW INTERFACE DOT11RADIO WME**

**Function:** Displays the WME configuration of the specified interface or all radio interfaces.

**Command Syntax:** **show interface Dot11Radio [<interface number>] wme**

**Command Description:**

Parameter	Value
interface number	Radio interface number. Depending on the unit, the value can be set to 0, 1 or 2 for units with three interfaces, or to 0 or 1 for units with two interfaces. The last interface is used for 5GHz communications and all other radio interfaces are used for 2.4GHz communications. This parameter is optional. If not specified, the WME configuration for all radio interfaces is displayed.

**Example:** show interface Dot11Radio 0 wme

**Permission Level:** viewer

**Related Commands:**

configure interface Dot11Radio wme

configure interface Dot11Radio wme-enable

## SHOW INTERFACE FASTETHERNET

**Function:** Displays the current Fast Ethernet configuration of the specified interface.

**Command Syntax:** **show interface FastEthernet <interface number>**

**Command Description:**

Parameter	Value
interface number	FastEthernet interface number. In this version the interface is always set to 0.

**Example:** show interface FastEthernet 0

**Permission Level:** viewer

**Related Commands:**

configure interface FastEthernet add-vlan-tag

configure interface FastEthernet auto-negotiation

show interface FastEthernet stats

## SHOW INTERFACE FASTETHERNET STATS

**Function:** Displays the Fast Ethernet statistics of the specified interface.

**Command Syntax:** **show interface FastEthernet <interface number> stats**

**Command Description:**

Parameter	Value
interface number	FastEthernet interface number. In this version the interface is always set to 0.

**Example:** show interface FastEthernet 0 stats

**Permission Level:** viewer

**Related Commands:**

```
configure interface FastEthernet auto-negotiation  
show interface FastEthernet
```

## SHOW INTERFACE SSIDS

**Function:** Displays information on the current SSIDs for each interface.

**Command Syntax:** `show interface ssids`

**Command Description:**

Parameter	Value
None	

**Example:** `show interface ssids`

**Permission Level:** viewer

**Related Commands:**

```
configure interface Dot11Radio ssid  
configure ssid  
configure ssid remove  
configure ssid rename  
show ssid params
```

## SHOW INTERFACE WIFI-LOAD-RATIO

**Function:** Displays the Wi-Fi load ratio of the radio interfaces. The table displays the following information:

- Clear Count Ratio – Displays the current Wi-Fi load in a percentage of the maximum air occupancy. Clear count load is the summation of the loads due to RX Frames, TX Frames and noise.
- RX Frame Count – Displays the Wi-Fi load associated with valid received frames in a percentage of the maximum air occupancy.
- TX Frame Count – Displays the Wi-Fi load associated with transmitted frames in a percentage of the maximum air occupancy.

**Command Syntax:** `show interface wifi-load-ratio`

**Command Description:**

Parameter	Value
None	

**Example:** `show interface wifi-load-ratio`

**Permission Level:** viewer

**Related Commands:**

```
show spectrum-management clear-count-percent
```

## SHOW INTERFACE WIFI-STATS

**Function:** Displays information related to each of the radio interfaces. The table displays the following information:

- Power Saving Stations – Displays number of clients in power savings mode that are connected to each interface.
- Associated Stations – Displays number of clients that are connected to each interface.

**Command Syntax:** `show interface wifi-stats`

**Command Description:**

Parameter	Value
None	

**Example:** `show interface wifi-stats`

**Permission Level:** viewer

**Related Commands:**

`configure interface Dot11Radio dtim-period`

`configure interface Dot11Radio sensitivity`

## SHOW IP ADDRESS

**Function:** Displays the configuration of the management interface parameters.

**Command Syntax:** `show ip address`

**Command Description:**

Parameter	Value
None	

**Example:** `show ip address`

**Permission Level:** viewer

**Related Commands:**

`configure ip vlan`

`configure ip default-gateway`

## SHOW IP PARAMS

**Function:** Displays the configuration of telnet and SSH related parameters.

**Command Syntax:** `show ip params`

**Command Description:**

Parameter	Value
None	

**Example:** show ip params

**Permission Level:** viewer

**Related Commands:**

configure ip mtu  
configure ip ssh  
configure ip telnet  
show ip address  
show ip ssh-public-keys

## SHOW IP SSH-PUBLIC-KEYS

**Function:** Displays the configuration of the SSH public authorized keys.

**Command Syntax:** show ip ssh-public-keys

**Command Description:**

Parameter	Value
None	

**Example:** show ip ssh-public-keys

**Permission Level:** admin

**Related Commands:**

configure ip ssh  
show ip params

## SHOW LOGGED-IN-USERS

**Function:** Displays information about the users that are currently logged on the CLI.

**Command Syntax:** show logged-in-users

**Command Description:**

Parameter	Value
None	

**Example:** show logged-in-users

**Permission Level:** super

**Related Commands:**

configure username

## SHOW LOGGING DESTINATIONS

**Function:** Displays the configuration of the log destinations. It displays the status and the maximum level of messages that are sent to each destination. The configuration of the ram destination is also the configuration of the system log.

**Command Syntax:** **show logging destinations**

**Command Description:**

Parameter	Value
None	

**Example:** show logging destinations

**Permission Level:** viewer

**Related Commands:**

configure logging dest cli  
configure logging dest history  
configure logging dest rs232console  
show logging host  
configure logging module  
configure logging syslog ip-address  
show messages

## SHOW LOGGING HISTORY

**Function:** Displays the logging history.

**Command Syntax:** **show logging history**

**Command Description:**

Parameter	Value
None	

**Example:** show logging history

**Permission Level:** admin

**Related Commands:**

configure logging dest history

## SHOW LOGGING HOST

**Function:** Displays the log destination host and port. It displays Host's IP address and communication port.

**Command Syntax:** **show logging host**

**Command Description:**

Parameter	Value
None	

**Example:** show logging host

**Permission Level:** viewer

**Related Commands:**

configure logging syslog ip-address  
show logging destinations

## SHOW LOGGING MODULES-LEVEL

**Function:** Displays the log level of the modules. The level defines the level of details saved in the log. The higher the number displayed the more details that are recorded.

**Command Syntax:** **show logging modules-level**

**Command Description:**

Parameter	Value
None	

**Example:** show logging modules-level

**Permission Level:** admin

**Related Commands:**

configure logging module  
show messages

## SHOW MAC-FILTER INDICES

**Function:** Displays the configuration of the current MAC filter lists.

**Command Syntax:** **show mac-filter indices**

**Command Description:**

Parameter	Value
None	

**Example:** show mac-filter indices

**Permission Level:** viewer

**Related Commands:**

configure mac-filter list new  
configure mac-filter list remove-list

## SHOW MAC-FILTER LIST

**Function:** Displays the list of MAC addresses contained in the specified MAC filter lists.

**Command Syntax:** `show mac-filter list <index number>`

**Command Description:**

Parameter	Value
index number	Index number of an existing MAC filter list: 1-16

**Example:** `show mac-filter list 3`

**Permission Level:** viewer

**Related Commands:**

`configure mac-filter list add-mac`

`configure mac-filter list new`

`configure mac-filter list remove-list`

`configure mac-filter list remove-mac`

## SHOW MANUFACTURE-DETAILS

**Function:** Displays the unit's serial number and MAC address.

**Command Syntax:** `show manufacture-details`

**Command Description:**

Parameter	Value
None	

**Example:** `show manufacture-details`

**Permission Level:** viewer

**Related Commands:**

None

## SHOW MESH INTERFACE-WDS-PARAMS

**Function:** Displays the WDS parameters for each radio interface.

**Command Syntax:** `show mesh interface-wds-params`

**Command Description:**

Parameter	Value
None	

**Example:** `show mesh interface-wds-params`

**Permission Level:** super

**Related Commands:**

configure mesh interface Dot11Radio wds  
configure mesh interface Dot11Radio wds-peer  
configure mesh interface Dot11Radio wds-privacy  
show mesh route  
show mesh wds-peer-list

## SHOW MESH FILTER-LIST

**Function:** Displays the mesh filtering configuration of the unit. It displays whether mesh filtering is enabled, the type of mesh filter list and the list of MAC addresses in the list.

**Command Syntax:** **show mesh filter-list**

**Command Description:**

Parameter	Value
None	

**Example:** show mesh filter-list

**Permission Level:** admin

**Related Commands:**

configure mesh filter-list  
show mesh params

## SHOW MESH PARAMS

**Function:** Displays the mesh configuration of the unit. It displays the mesh timeout, mesh interface, mesh security settings and whether the unit has been defined as a Mesh-Gateway or Mesh-Node.

**Command Syntax:** **show mesh params**

**Command Description:**

Parameter	Value
None	

**Example:** show mesh params

**Permission Level:** viewer

**Related Commands:**

configure mesh connectivity\_test  
configure mesh interface  
configure mesh mode  
configure mesh privacy

## SHOW MESH ROUTE

**Function:** Displays a routing table that contains the routing entry for the current next hop to get access to the Mesh-Gateway. It also displays all the alternative next hop routing entries.

**Command Syntax:** **show mesh route**

**Command Description:**

Parameter	Value
None	

**Example:** show mesh route

**Permission Level:** super

**Related Commands:**

configure mesh interface Dot11Radio wds  
configure mesh reroute-now  
show mesh params  
show mesh wds-peer-list

## SHOW MESH STAND-ALONE

**Function:** Displays the current stand alone mode and status.

**Command Syntax:** **show mesh stand-alone**

**Command Description:**

Parameter	Value
None	

**Example:** show mesh stand-alone

**Permission Level:** super

**Related Commands:**

configure mesh stand-alone  
configure mesh stand-alone-passphrase  
configure mesh interface  
configure mesh mode  
configure mesh privacy

## SHOW MESH WDS-PEER-LIST

**Function:** Displays the WDS peers.

**Command Syntax:** `show mesh wds-peer-list`

**Command Description:**

Parameter	Value
None	

**Example:** `show mesh wds-peer-list`

**Permission Level:** super

**Related Commands:**

`configure mesh interface Dot11Radio wds`  
`configure mesh interface Dot11Radio wds-peer`  
`configure mesh interface Dot11Radio wds-privacy`  
`show mesh interface wds-params`  
`show mesh route`

## SHOW MESSAGES

**Function:** Displays the specified message types from the system log.

**Command Syntax:** `show messages <message type>`

**Command Description:**

Parameter	Value
message type	defaults-loading – Displays all the messages that contain commands related to default configuration loading and their results. config-loading – Displays all the messages that contain commands related to startup configuration loading and their results. software-loading – Displays all the messages related to software downloading.

**Example:** `show messages software-loading`

**Permission Level:** admin

**Related Commands:**

`configure logging dest history`  
`show logging destinations`  
`show logging modules-level`  
`show softload-messages`

## SHOW NTP

**Function:** Displays the current configuration of the NTP client on the unit.

**Command Syntax:** `show ntp`

**Command Description:**

Parameter	Value
None	

**Example:** show ntp

**Permission Level:** super

**Related Commands:**

configure ntp

## SHOW PINGWD

**Function:** Displays the current configuration of the ping watchdog feature.

**Command Syntax:** show pingwd

**Command Description:**

Parameter	Value
None	

**Example:** show pingwd

**Permission Level:** super

**Related Commands:**

configure pingwd

## SHOW PRIVACY WEP

**Function:** Displays the current configuration for all the WEP keys.

**Command Syntax:** show privacy wep

**Command Description:**

Parameter	Value
None	

**Example:** show privacy wep

**Permission Level:** viewer

**Related Commands:**

configure privacy wep ssid index

configure ssid

show privacy wep params

show ssid params

## SHOW PRIVACY WEP PARAMS

**Function:** Displays the current configuration for the WEP parameters.

**Command Syntax:** `show privacy wep params`

**Command Description:**

Parameter	Value
None	

**Example:** `show privacy wep`

**Permission Level:** viewer

**Related Commands:**

`configure privacy wep ssid index`  
`configure ssid`  
`show privacy wep`  
`show ssid params`

## SHOW PRIVACY WPA

**Function:** Displays the current information on WPA privacy.

**Command Syntax:** `show privacy wpa`

**Command Description:**

Parameter	Value
None	

**Example:** `show privacy wpa`

**Permission Level:** admin

**Related Commands:**

`configure ssid`  
`configure privacy wpa`  
`show ssid params`

## SHOW RADIUS

**Function:** Displays configuration for the specified radius server.

**Command Syntax:** `show radius {accounting | authentication | params}`

**Command Description:**

Parameter	Value
<code>accounting   authentication   params</code>	accounting – Displays the configuration of the accounting Radius server. authentication – Displays the configuration of the authentication Radius server. params – Displays the general parameters of the Radius server.

**Example:** show radius params

**Permission Level:** viewer

**Related Commands:**

configure radius  
configure radius interim-interval  
configure radius retry-primary-interval

## SHOW RECOVERY-SSID STATUS

**Function:** Displays the current status of the recovery SSID mode.

**Command Syntax:** show recovery-ssid status

**Command Description:**

Parameter	Value
None	

**Example:** show recovery-ssid status

**Permission Level:** super

**Related Commands:**

configure recovery-ssid

## SHOW RUNNING-CONFIG

**Function:** Displays the current configuration of the unit. This configuration is saved in volatile memory.

**Command Syntax:** show running-config

**Command Description:**

Parameter	Value
None	

**Example:** show running-config

**Permission Level:** admin

**Related Commands:**

## SHOW SITESURVEY

**Function:** Displays the test results of the latest site survey of all available channels. These results can then be used to assist you in selecting the best available channel.

To perform a site survey, use the *configure sitesurvey* command.

**Command Syntax:** **show sitesurvey**

**Command Description:**

Parameter	Value
None	

**Example:** **show sitesurvey**

**Permission Level:** admin

**Related Commands:**

configure interface Dot11Radio channel  
configure interface Dot11Radio channel-list  
configure sitesurvey  
show interface Dot11Radio params  
show interface Dot11Radio channel-list

## SHOW SNMP-COMMUNITIES

**Function:** Displays the current SNMP community names.

**Command Syntax:** **show snmp-communities**

**Command Description:**

Parameter	Value
None	

**Example:** **show snmp-communities**

**Permission Level:** viewer

**Related Commands:**

configure snmp rocommunity  
configure snmp rwcommunity

## SHOW SOFTLOAD-MESSAGES

**Function:** Displays the messages related to the *import image* command and its results.

**Command Syntax:** **show softload-messages**

**Command Description:**

Parameter	Value
None	

**Example:** show softload-messages

**Permission Level:** admin

**Related Commands:**

import image

show messages

## SHOW SOFTWARE-BANKS

**Function:** Displays information on the unit's software memory banks. It displays a table that shows which software version is in each bank and which bank is active. It also displays which bank will be active for the next restart.

**Command Syntax:** **show software-banks**

**Command Description:**

Parameter	Value
None	

**Example:** show software-banks

**Permission Level:** admin

**Related Commands:**

import image

show version

## SHOW SPECTRUM-MANAGEMENT CLEAR-COUNT-PERCENT

**Function:** Displays the Clear Count ratio of the radio interfaces and other related data. The table displays the following information:

- TX Frame Count – Displays the Wi-Fi load associated with transmitted frames in a percentage of the maximum air occupancy.
- RX Frame Count – Displays the Wi-Fi load associated with valid received frames in a percentage of the maximum air occupancy.
- Clear Count Ratio – Displays the current Wi-Fi load in a percentage of the maximum air occupancy. Clear count load is the summation of the loads due to RX Frames, TX Frames and noise.
- Sensitivity Level – Displays the sensitivity setting for each interface.
- Noise Level – Displays the sensitivity level for each interface. This defines the noise floor level in dBm.

**Command Syntax:** **show spectrum-management clear-count-percent**

**Command Description:**

Parameter	Value
None	

**Example:** show spectrum-management clear-count-percent

**Permission Level:** viewer

**Related Commands:**

configure interface Dot11Radio sensitivity  
show associated-stations  
show spectrum-management doa

**SHOW SPECTRUM-MANAGEMENT DOA**

**Function:** Displays the number of packets received from the clients per Direction of Arrival (DOA). The number of packets is displayed based on the angle from the antenna. It is displayed in 16 segments. The value displayed is the number of packets received during the last four seconds.

**Command Syntax:** show spectrum-management doa

**Command Description:**

Parameter	Value
None	

**Example:** show spectrum-management doa

**Permission Level:** viewer

**Related Commands:**

show associated-stations  
show spectrum-management clear-count-percent

**SHOW SSID PARAMS**

**Function:** Displays the current configuration for all SSIDs.

**Command Syntax:** show ssid params

**Command Description:**

Parameter	Value
None	

**Example:** show ssid params

**Permission Level:** viewer

**Related Commands:**

configure privacy wep ssid index

configure ssid

## SHOW STARTUP-CONFIG

**Function:** Displays the startup configuration of the unit. This configuration is saved in non-volatile memory and is used when starting the unit.

**Command Syntax:** `show startup-config`

**Command Description:**

Parameter	Value
None	

**Example:** `show startup-config`

**Permission Level:** admin

**Related Commands:**

`delete startup-config`  
`copy running-config startup-config`  
`export startup-config`  
`import startup-config`

## SHOW SYSTEM-TEMPERATURE

**Function:** Displays the temperature of the unit's internal modules.

**Command Syntax:** `show system-temperature`

**Command Description:**

Parameter	Value
None	

**Example:** `show system-temperature`

**Permission Level:** super

**Related Commands:**

None

## SHOW TC-DEFAULT-PROFILE

**Function:** Displays the default Traffic Control profile of the unit. This profile is the default profile that is assigned to SSIDs. It is used to define maximum throughput.

**Command Syntax:** `show tc-default-profile`

**Command Description:**

Parameter	Value
None	

**Example:** show tc-default-profile

**Permission Level:** admin

**Related Commands:**

configure ssid  
 configure tc  
 configure tc-default-profile  
 configure tc-profile modify  
 configure tc-profile new  
 configure tc-profile remove  
 show tc-profiles

**SHOW TC-PROFILES**

**Function:** Displays all the existing Traffic Control profile. These profiles are used in configuring SSIDs to define maximum throughput.

**Command Syntax:** show tc-profiles

**Command Description:**

Parameter	Value
None	

**Example:** show tc-profiles

**Permission Level:** viewer

**Related Commands:**

configure ssid  
 configure ssid ssid-profile  
 configure ssid user-profile  
 configure tc  
 configure tc-default-profile  
 configure tc-profile modify  
 configure tc-profile new  
 configure tc-profile remove  
 show tc-default-profile

**SHOW TRAP-NOTIFY-FILTERS**

**Function:** Displays a table of all the trap categories and their current trap filter settings. When a category is enabled the traps associated this category is sent to the trap targets. To configure settings of the trap filter, use the *configure trap-notify-filter* command.

**Command Syntax:** `show trap-notify-filter`

**Command Description:**

Parameter	Value
None	

**Example:** `show trap-notify-filters`

**Permission Level:** super

**Related Commands:**

`configure trap-notify-filter`  
`configure trap-target add`  
`configure trap-target remove`  
`show trap-targets`

## SHOW TRAP-TARGETS

**Function:** Displays a table containing all current trap targets in the unit. Each trap target displayed includes the configuration definition for sending traps to the target.

**Command Syntax:** `show trap-targets`

**Command Description:**

Parameter	Value
None	

**Example:** `show trap-targets`

**Permission Level:** viewer

**Related Commands:**

`configure trap-notify-filter`  
`configure trap-target add`  
`configure trap-target remove`  
`show trap-notify-filters`

## SHOW UPTIME

**Function:** Displays time the system has been running since the last restart.

**Command Syntax:** `show uptime`

**Command Description:**

Parameter	Value
None	

**Example:** `show uptime`

**Permission Level:** viewer

## SHOW USERS

**Function:** Displays the table of all configured local users.

**Command Syntax:** **show users**

**Command Description:**

Parameter	Value
None	

**Example:** show users

**Permission Level:** admin

**Related Commands:**

configure username

## SHOW VERSION

**Function:** Displays the current firmware version and release date.

**Command Syntax:** **show version**

**Command Description:**

Parameter	Value
None	

**Example:** show version

**Permission Level:** viewer

## SHOW WEB STATUS

**Function:** Displays the current status of the web service.

**Command Syntax:** **show web status**

**Command Description:**

Parameter	Value
None	

**Example:** show web status

**Permission Level:** super

**Related Commands:**

configure web

# Appendix A

---

## List of Acronyms

<b>Acronym</b>	<b>Explanation</b>
802.11	A family of specifications related to wireless networking, including: 802.11a, 802.11b, and 802.11g.
AP	Access Point. The hub of a wireless network. Wireless clients connect to the access point, and traffic between two clients must travel through the access point. Access points are often abbreviated to AP
BSSID	Broadcast Service Set Identifier
CPE	Customer Premises Equipment
DHCP	Dynamic Host Configuration Protocol. A protocol which enables a server to automatically assign an IP address to clients so that the clients do not have to configure the IP addresses manually.
EAP	Extensible Authentication Protocol. A standard form of generic messaging used in 802.1X.
ESSID	EGOed Service Set Identifier
PMK	Pairwise Master Key
SSID	Service Set Identifier, a set of characters that give a unique name to a WLAN.
TKIP	Temporal Key Integrity Protocol
VLAN	Virtual Local Access Network
WDS	Wireless Distribution System
WEP	Wired Equivalent Privacy. An encryption system created to prevent eavesdropping on wireless network traffic.

WMG	Wireless Media Gateway of the Netronics solution.
WNC	Wireless Network Controller of the Netronics solution.
WPA	Wi-Fi Protected Access. A modern encryption system created to prevent eavesdropping on wireless network traffic. It is considered more secure than WEP.
WPA-EAP	WPA-Extensible Authentication Protocol
WPA-PSK	WPA-Pre-Shared Key

# Appendix B

## Wiring Specifications

Console Port (DTE)	RJ-45-to-RJ-45 Straight Cable		RJ-45 to DB-9 Terminal Adapter	Console Device
Signal	RJ-45 Pin	RJ-45 Pin	DB-9 Pin	Signal
No connection	1	1	8	CTS
No connection	2	2	6	DSR
No connection	3	3	5	GND
GND	4	4	5	GND
RxD	5	5	3	TxD
TxD	6	6	2	RxD
No connection	7	7	4	DTR
No connection	8	8	7	RTS

Table 1: Console Port Signalling and Cabling with a DB-9 Adapter for the NetPoint Pro 6x2.4 Unit

# Appendix C

---

## Power Up and Software Configuration

The NetPoint Pro units are normally mounted on streetlights (poles or walls) where it is inconvenient to configure. Therefore, it is recommended that wireless communication be established to the unit prior to installation, so that the unit can later be configured and monitored remotely. To verify communications when installing the unit, the Mesh-Gateways must be installed and powered up first.

The LEDs on the unit indicate the status of communications between the unit and the network. See Table 5 for more information on the LED indicators.

The ACT LED on the Mesh-Gateway should be checked to verify that wired communications have been established. The BH LED on the Mesh-Gateway should be checked to verify that wireless communications have been established.

When powering up a Mesh-Node, the BH LED should be lit to verify that the unit's wireless communication is connected. The boot time is about 2.5 minutes. The BH LED indicator will light up after the boot is completed.

LED	Function
PWR	<b>Green</b> – There is power to the unit. <b>Unlit</b> – There is no power to the unit.
STAT	<b>Green</b> – The operational status of the unit is normal. <b>Red</b> – The unit is in a failure state. <b>Unlit</b> – There is no power to the unit.
ACT	<b>Green</b> – When the LED is on, there is a communication connection. When the LED is flashing, traffic is flowing through the unit. <b>Unlit</b> – There is no communication connection.
BH	<b>Green</b> – On a Mesh-Gateway, the mesh functionality is activated. On a Mesh-Node, the unit is connected to the mesh. <b>Unlit</b> – On a Mesh-Gateway, the mesh functionality is not activated or no Ethernet link is available. On a Mesh-Node, the unit is not configured or failed to connect to the mesh.

Table 2: LED Indicators